## Steering Repairs and maintenance

10

Section Group 64 Steering 1975-240/260

# VOIJVO

## Contents

|   | Op.                                  | Page                 |
|---|--------------------------------------|----------------------|
| Specification   |                                      | . 2                  |
| Service procedures  |                                      |                      |
| Replacing steering column or steering lock                              | A1-A43                               | 9                    |
| Manual steering gear, removal   | B1-B6                                | 16                   |
| Steering gear type Cam Gear:<br>Disassembly                             | C1-C13                               | 17                   |
| Assembly  | D1-D21                               | 22                   |
| Steering gear type ZF:  | E1_E12                               | 27                   |
| Illustration<br>Assembly  | F1-F20                               | 30<br>31             |
| Manual steering gear, installation                                      | G1-G8                                | 36                   |
| Power steering gear, removal  | H1-H8                                | 38                   |
| Power steering gear type Cam Gear:<br>Disassembly<br>Illustration       | 11-125                               | 40<br>47             |
| Assembly<br>Installation<br>Adjusting balance<br>Installation continued | J1-J52<br>K1-K6<br>K7-K27<br>K28-K39 | 49<br>61<br>63<br>68 |
| Power steering gear type ZF:<br>Checking balance                        | L1-L6                                | 71                   |
| Power steering pump Saginaw:<br>Disassembly                             | M1-M11                               | 73                   |
| Assembly  | N1-N12                               | 76                   |
| Power steering pump ZF:   | 01.00                                | 00                   |
| Illustration  | P1_P1/                               | 83                   |
| Assembly  | F1-F14                               | 04                   |

**TP 30001/3** 4500.8.84 Printed in U.S.A.

We reserve the right to make alterations

© 1984, VOLVO OF AMERICA CORPORATION

## Group 64 Steering 1975-



steering gear

Specifications

## Specifications

Front end alignment



129581

Vehicles unloaded

#### Toe-in

The toe-in should be set as follows:

|          | angle 2 a | А-а          | B-b         | C-c         |
|----------|-----------|--------------|-------------|-------------|
| Manual   | 24' ± 8'  | 4.5 ± 1.6 mm | 3.5 ± 1 mm  | 2.5 ± 1 mm  |
|          |           | 3/16":±1/16" | 9/64"±1/32" | 3/32"±1/32" |
| Power    | 16' + 8'  | 3.0 ± 1.5 mm | 2.0 ± 1 mm  | 1.5 ± 1 mm  |
| otooning |           | 1/8"±1/16"   | 5/64"±1/32" | 1/16±1/32"  |

Vehicle should not be loaded. Measurements must be made at center (hub) height. a is an angle, read on certain instruments. A, B, and C refer to tire outer diameter, tire inner shoulder and rim, respectively.

| Caster (not to exceed | 1/2° difference | between sides) | +2° to +3° |
|-----------------------|-----------------|----------------|------------|
| with power steering   |                 |                | +3° to +4° |

Camber (difference not to exceed 1/2° between left and right side) +1° to +11/2°

#### Specifications

#### Manual steering gear, Cam Gear

| Type<br>No of turns from lock to lock<br>Ratio                       | Rack and pinion<br>4.34<br>21.4:1                             |                  |
|--|---|------------------|
| Pinion: pre-tension<br>shims available                               | 0,1 mm<br>0.127 mm<br>0.191 mm<br>0.254 mm                    | 0.004"           |
| Clearance between pre-tensioning piston and cover<br>Shims available | 0.002-0.15 mm<br>0.127 mm<br>0.254 mm<br>0.381 mm<br>0.508 mm | 0.0008-0.006"    |
| Pre-tension pinion to rack   | 0.6-1.7 nm<br>Volvo P/N 1161001                               | 0.44–1.25 ft.lb. |
| Quantity   | 75 grams  | 2.5 oz.          |

#### Manual steering gear, ZF

| Туре                           | Rack and pinion  |                  |
|--------------------------------|------------------|------------------|
| No. of turns from lock to lock | 4.34             |                  |
| Ratio                          | 21.4:1           |                  |
| Pre-tension pinion to rack     | 0.6-1.7 Nm       | 0.44-1.25 ft.lb. |
| Lubricant                      | Volvo P/N 116100 | 1                |
| Quantity                       | 75 grams         | 2.5 oz.          |
|                                |                  |                  |

#### Power steering gear, Cam Gear (Early type)

| No. of turns from lock to lock                                       | Rack and pinion 3.5  |               |
|--|--|---------------|
| nauo   | 17.2:1   |               |
| Pinion: gaskets for pinion pre-tension                               | P/N 1206931, 12  | 06934         |
| Clearance between pre-tensioning piston and cover<br>Shims available | 0.05–0.15 mm<br>0.051 mm<br>0.089 mm<br>0.127 mm<br>0.254 mm | 0.002-0.006'' |
| Pre-tension pinion to rack<br>Checking balance:                      | 0.9-1.7 Nm   | 8-15 in.lbs.  |
| - Power pump pressure  | 1.2 MPa  | 170 psi       |
| - at torque reading  | 3.5-5.0 Nm   | 30-40 in.lbs. |
| Difference between sides must not exceed                             | 1.0 Nm   | 0.73 ft.lb.   |
| Lubricant ("Lubricant for steering gear")                            | Volvo P/N 116100   | 01-1          |
| Quantity   | 0.2 liter  | 0.2 qt.       |
| Power pump oil   | ATF  |               |
| Quantity: integrated oil reservoir                                   | 0.7 liter  | 0.65 qt.      |
| separate oil reservoir   | 1.2 liter  | 1.1 qt.       |
|  |  |               |

#### Specifications

#### Power steering gear, ZF (Fixed Valve Housing)

| Checking balance:                        |          |
|--|----------|
| - Power pump pressure                    | 2.0 MPa  |
| - at torque reading                      | 4-5.5 Nm |
| Difference between sides must not exceed | 0.5 Nm   |

285 psi 35-40 in.lb. 4.4 in.lb.



#### Power steering pump, ZF

| Туре                            | Vane pump      |                       |
|---------------------------------|----------------|-----------------------|
| Max. pressure, early prod       | 7.5 MPa        | 1070 psi              |
| late prod                       | 5.8 MPa        | 820 psi               |
| Theoretical capacity at 500 rpm | 6.65 liter/min | 6.24 gt/min           |
| Drive                           | Belt drive     | and the second second |
| Drive ratio, engine to pump     | 1:1            |                       |

#### Power steering pump, Saginaw

| Туре                            | Vane pump   |             |
|---------------------------------|-------------|-------------|
| Max. pressure                   | 5.5-7 MPa   | 780-995 psi |
| Theoretical capacity at 500 rpm | 5 liter/min | 5.3 qt/min  |
| Drive                           | Belt drive  |             |
| Drive ratio, engine to pump     | 1:0.9       |             |

#### Torques

| Nm  | ft.lb.   |
|---|--|
| $60\pm 15$<br>20 $\pm 5$<br>20 $\pm 5$<br>23 $\pm 5$<br>20 $\pm 5$<br>70 $\pm 10$ | $ \begin{array}{r} 44\pm11\\ 14\pm4\\ 14\pm4\\ 17\pm4\\ 14\pm4\\ 51\pm7 \end{array} $  |
|   |  |
| 24±2  | 17±1.5   |
|   |  |
| 19±2<br>19±2  | 14±1.5<br>14±1.5   |
|   |  |
| 19±2<br>19±2<br>19±2<br>19±2<br>19±2<br>14±1                                      | $14 \pm 1.5 \\ 14 \pm 1.5 \\ 14 \pm 1.5 \\ 14 \pm 1.5 \\ 10 \pm 0.75 \\ 20 \pm 5 \\ 10 \pm 5 \\$ |
|   | Nm<br>$60\pm15$<br>$20\pm5$<br>$20\pm5$<br>$23\pm5$<br>$20\pm5$<br>$70\pm10$<br>$24\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$19\pm2$<br>$14\pm1$<br>$42\pm7$   |



## Special tools

When ordering tools, put 999 in front of 4-digit tool number.

|   | 1801 | Standard handle                           | 5051 | Puller  |
|---|------|---|------|---|
|   | 1819 | Bearing puller                            |      | bearing and seal                                    |
|   | 2263 | Steering wheel puller                     | 5052 | Drift   |
|   | 2520 | Work stand                                |      | installing bearing                                  |
|   | 2734 | Drift<br>installing seal                  | 5053 | Adapter<br>checking pinion torque                   |
|   | 2863 | Drift<br>installing seal                  | 5054 | Cover<br>adjusting balance                          |
|   | 2993 | Drift<br>installing rack bushing Cam Gear | 5055 | Pressure gauge<br>balance and oil pressure          |
|   |      | manual steering gear                      | 5056 | Sleeve  |
|   | 4078 | Puller                                    |      | installing seal                                     |
|   |      | rack bushing                              | 5119 | Wrench  |
|   | 5043 | Puller<br>tie rod end                     |      | lock nut, pinion upper bearing,<br>ZF steering gear |
|   | 5046 | Fixture<br>steering gear overbaul         | 5175 | Nipple<br>checking balance                          |
| ) | 5047 | Puller<br>for bearing                     | 5176 | Nipple<br>checking balance                          |
|   | 5048 | Drift<br>installing bearing               | 5179 | Adapter<br>checking balance                         |
|   | 5049 | Sleeve<br>adjusting balance               | 5182 | Adapter<br>installing cover                         |
|   |      | adjusting balance                         | 9177 | Torque gauge  |
|   |      |   |      |   |



1810 Standard handle



1819 Bearing puller



2263 Steering wheel puller

5

#### Special tools



2520 Work stand 5046 Fixture steering gear overhaul



2734 Drift installing seal



2863 Drift installing seal



2993 Drift installing rack bushing, Cam Gear



4078 Puller rack bushing



5043 Puller tie rod end



5047 Puller for bearing

6





5048 Drift installing bearing



5049 Sleeve adjusting balance

Special tools



5051 Puller bearing and seal



5052 Drift installing bearing



5053 Adapter checking pinion torque 9177 Torque gauge



5054 Cover adjusting balance



5055 Pressure gauge balance and oil pressure 5175 5176 Nipples checking balance



5056 Sleeve installing seal



5119 Wrench lock nut, pinion upper bearing, ZF



5179 Adapter checking balance



5182 Adapter installing cover



## **Replacing steering column or steering lock**

#### Special tools:

2263 Steering wheel puller (1976–1978) Deep thin wall socket (1979–)





A13

A14



#### Check the steering column.

Check that the upper crumple zone is intact. Its upper end (A) should not move axially in relation to the lower end (B).

The overall length of the steering column should be:

Models:

1976-1978 689±1 mm = 27.126"±0.04"

 $1979-704\pm1 \text{ mm} = 27.717''=0.04''$ 

Install the steering lock .

Position the lock so that the distance between the lock upper part and the end of the tube is  $97 \text{ mm} = 3.82^{\circ}$ .

A15

A16

#### Check the two plastic guides.

They must be provided with spacers and turned so that the washers are DOWN.



Position the steering column.

Screw in the shearing bolts but do not tighten.



ale

in









Position the rubber seal on the dashboard. Loosely fit the upper joint on the upper steering shaft.

A24

A23

Attach the lower steering shaft flange to the upper joint .

Torque:  $23\pm5$  Nm =  $17\pm4$  ft.lbs.

A25

For 1979 and later Models and for 1978 Models equipped with ZF power steering gear:

#### Check steering shaft .

Following any repair to the steering shaft.

The distance A between the upper joint and the shoulder on the lower steering shaft should be:

If incorrect, the distance should be adjusted as follows:

#### A26

#### Pull up the protection for the lower joint.

(Not power steering equipped.)

A27

#### Loosen the joints.

Loosen the screws B at the lower joint and C at the upper joint just so much that the screw head comes free from the joint.

#### Adjust the distance A.

A28

Move lower shaft up or down. Be careful not to change the position of the upper steering shaft as it will influence the distance between the steering wheel and the covers.

A29

#### Retighten the joints.

Torque:  $23\pm5$  Nm =  $17\pm4$  ft.lbs.

Refit the lower joint protection (not vehicles with power steering).

128 596



128 59

#### A30

### Adjust distance between steering wheel and steering wheel cover.

Operations A25-A29 must be completed.

#### A31

A32

#### Pull up the protection for the lower joint.

#### Loosen lower joint.

Loosen the screw B at the lower joint just so much that the screw head comes free from the joint.

A33

#### Adjust distance E.

Move the lower steering shaft to obtain a clearance of  $1-2 \text{ mm} = 0.04-0.08^{\circ\circ}$  between the steering wheel and the covers.

A34

#### Retighten the joint.

Torque:  $23\pm5$  Nm =  $17\pm4$  ft.lbs. Refit the lower joint protection.

A35

## Attach the switch retainer. Reconnect the wires.

Use one of the retaining screws to attach the ground wire.

Reconnect the wire connector.

A36

A37

Install upper and lower steering column covers .



Manual steering gear Removal

## Manual steering gear

Removal

Special tool: 5043 Tie rod end puller



Manual steering gear, Cam Gear Disassembly



## Disconnect the steering gear at the front axle beam.

First remove the splash shield under the engine. Save rubber spacers and plates.

-----



B6

**B**5

Disconnect the steering gear at the steering shaft flange. Remove the steering gear.

Save the dowel pins.

## Steering gear type Cam Gear

Special tools: 2520 Work stand 2734 Drift 4078 Puller 5046 Fixture

5047 Drift

Disassembly

Cleanliness

#### CAUTION

Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.

Repairs to the power steeing system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.

C1



#### Install the steering gear on a stand.

Use stand 2520 and fixture 5046. Use the U-bolt from the vehicle.

Manual steering gear, Cam Gear Disassembly



Clean the exterior of the steering gear. Check inner and outer joints for wear.

C2

C3

C4

C5



Disconnect the rubber bellows at the steering gear housing.

Early type steering gears: collect the oil in a pan.

Bend up locked portion of ball joints. Use a narrow chisel.





Use a 18 mm = 23/32" wrench to hold the rack on the outermost tooth.

Use a 32 mm = 1-9/32" wrench to turn the ball joint.

Manual steering gear, Cam Gear Disassembly

C6

Remove the cover for the pre-tensioning device.



Remove spring, piston and O-ring. No O-ring on steering gear lubricated with grease.

Remove pinion cover.

C8

C9

C7



125 403

125 404

Remove pinion and spacer sleeve.

Manual steering gear, Cam Gear Disassembly



4078

C10 Pull out the rack toward the pinion side of the steering gear.

C11

C13

Remove rack bushing. Use puller 4078.

Remove pinion lower bearing. Use puller 5047 or 1819 as applicable.

5047 5047 725-407

128 628

Clean, check, replace parts.

Always replace rack bushing and seals.

Replace both pinion bearings if they are early type. Late type bearings are equipped with plastic ball retainers which prevent steering gear seizure.

Manual steering gear, Cam Gear Illustration



Steering gear Cam Gear Manual steering gear, Cam Gear

## Steering gear type Cam Gear

#### Assembly

#### Special tools:

2734 Drift 2993 Drift 5048 Drift 5053 Adapter 9177 Torque meter

#### Lubricant:

Grease P/N 1161001-1 (approx. 100 grams = 3.5 oz.)



5048

#### Install the rack.

D1

D2

Position bushing so that locks align to housing slots. Use drift 2993 to install the bushing.

Install pinion lower bearing. Use drift 5048.

D3 Position pinion and upper bearing assem-

Note: no shims on the upper bearing.

bly in the housing.





#### Manual steering gear, Cam Gear





### Install the pre-tensioning piston in the housing and determine clearance.

The piston should be without O-ring and spring. Use feeler gauge and ruler to determine the clearance from the piston end to the housing surface.

Move the rack from end to end and measure at the position where the largest clearance is obtained.

#### D15

D14

#### Determine shims and gasket.

Shims and gasket should together equal determined clearance plus 0.05-0.15 mm = 0.002-0.006."

#### D16

Install spring and O-ring in the piston. No O-ring on steering gear lubricated with grease.

D17 Install cover with shims and gasket. Torque:  $19\pm2$  Nm = 14-1.5 ft.lbs.









Manual steering gear ZF

## Steering gear type ZF

Disassembly

Special tool: 5119 Wrench

#### Cleanliness



Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.

Repairs to the power steering system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.

Summer and the second s

Bun

#### Clean the steering gear exterior. Install the steering gear in a vise. Check the ball joints.

Use a vise with soft jaws. Check inner and outer ball joints for wear.

E2

E1

#### Remove the rubber bellows. Bend up the steering rod locks.

The rubber bellows are held in place by flanges. Use hands to pull them loose.

#### E3



Use a 22 mm = 7/8'' wrench to hold on the outermost tooth of the rack.

Use a 27 mm = 1-1/16'' wrench to unscrew the joint.



Remove the dust seal over the pre-

tensioning device.



Remove the cotter pin. Remove the cover.

Use wrench 5119. Save the spring inside the cover.



Remove the pre-tensioning piston.

Removal might be facilitated by knocking rack with palm.



Remove pinion dust seal.

E7

E6

E4

#### Manual steering gear ZF





3

## Steering gear type ZF

#### Assembly

125 439

125 440

128 441

#### Special tools:

5053 Adapter 5119 Wrench 9177 Torque meter Lubricant: Grease P/N 1161001-1

Press the bearing onto the pinion.

F2

F3

F4

F1

Install lock ring and thrust washer.

Install new O-rings on the rack bushing.








#### Manual steering gear ZF



Manual steering gear Installation

## Manual steering gear

Installation on vehicle



36 Group 64 Steering

#### Manual steering gear Installation



Power steering gear Removal

## Power steering gear

Removal

Special tool: 5043 tie rod end puller



Power steering gear Removal



# Power steering gear type Cam Gear.

#### Disassembly

#### Special tools:

1801 Pull hammer 2520 Work stand 5046 Fixture 5049 Sleeve

5046

#### Cleanliness

CAUTION

Do not allow dirt or foreign matter to come in contact with power steering components. Contamination will cause malfunction of the system or leaks causing unnecessary repairs.

Repairs to the power steering system should be accomplished in a dirt and dust free area. Clean components thoroughly before disassembly.

11

12

13

**Install the steering gear on a stand.** Use work stand 2520 and fixture 5046. Use a U-bolt from the vehicle.



Clean the exterior of the steering gear. Check inner and outer joints for wear



Disconnect the rubber bellows from the steering gear. Drain the lubricant.

Early type steering gears: collect the oil in a pan.



#### Remove the tie rods.

Use a 7/8" wrench to hold the rack on the outermost tooth.

Use a 30 mm 1-3/16" wrench to turn the joint.

Remove the oil tubes.

*I*5

I4



R

125 805

125 806

Remove the pre-tensioning device. Remove cover, piston, O-ring and spring.

Remove the lower pinion cover. Remove the spacer sleeve. 17



5049

#### Bend up the locking tab. Remove the nut.

Use adapter 5053 to hold the outer end of the shaft. The valve should not move axially when removing the nut.

**I8** 

I10

I11

#### I9 Remove inner race with ball retainer and the cup.

Use tool 5049

Note: be sure to count the number of turns in order to obtain same pinion height when reinstalling.

Remove the valve housing cover. Remove the outer dust seal.



125 610

#### Disassemble the valve housing.

Remove the spring. Lift up the valve housing and the pinion.

Be careful not to damage valve and valve housing.

Group 64 42 Steering

I 12 Remove the lock screw for the right side housing. (note aluminum spacer washer)

125 61

128 613

125.614

*I 13* Pull off right side housing and connecting tube.

Pull out the rack and pinion sleeve.

I15 Remove the lock screw for the left side housing.

Note: special sealing washer with rubber insert.



I14





Check that outer tube and O-ring make good contact. (Slight resistance when removing).

#### I17

#### Pull out the inner tube.

Check that inner tube and O-ring make good contact.



125 816

Remove upper bearing and pinion seal. Use pull hammer 1819.

Remove lower bearing race.

As necessary and only if the bearing is replaced. Use two narrow screwdrivers to remove the race.



44 Group 64 Steering I 19

I18





Inner tube.

Remove snap ring, spacer washer and seal.

I24

125

#### Clean, inspect, replace.

Replace all seals, O-rings and the valve cover assembly. Piston seal: see step 123.

If the pinion, control valve or valve housing is damaged, replace the parts as an assembly.

The rack bearing assembly should be replaced if the bushing is damaged.



Power steering gear Cam Gear B21 1979–



Illustration for reference only Power steering gear Cam Gear B27 1979 B28 1980-



Illustration for reference only

# Power steering gear type Cam Gear

#### Assembly

| Special tools:5052 Drift1801 Standard handle5053 Sleeve2520 Work stand5054 Cover5046 Fixture5056 Sleeve5049 Sleeve5175, 5176 Nipples  | 5182 Guide<br>9177 Torque gauge<br><b>Lubricant:</b><br>"Lubricant for steering gear' Volvo P/N 1161001-1.   |
|---|--|
| <image/> | J1<br>Oil all parts prior to assembly.<br>J2<br>Install the plastic ring and O-ring on the<br>rack bearing.  |
|   | J3<br>Install the snap ring on the inner tube.<br>Be careful not to scratch the sealing surface with<br>the snap ring.<br>Also check that the end of the tube has no sharp<br>edges that could damage the O-ring when inserting<br>the tube. |
|   | <b>Piston seal.</b><br>See step 1 23.<br>First install the O-ring and then the plastic ring.<br>Use the fingers to install the plastic ring. If difficult,<br>heat the ring to $40-50^{\circ}C = 100-120^{\circ}F$ .                         |





First fit the spacer washer (1) from the rack toothed side. Then cover the rack teeth with tape and fit the oil seal (2).



Fit plastic ring and second spacer washer.

Remove the tape. Fit plastic ring (3) and second spacer washer (4).



Install the seal in the left housing. The seal lip should face UP.



#### Install the bearing.

Prior to assembly, check that the bearing turns freely on the pinion shaft.

Use drift 5052 and standard handle 1801 to install the bearing.

*J6* 

J7

18

J9





#### Install two O-rings in left side housing.

Make sure O-rings protrude above the groove. If not housing must be replaced.

J10 Install spacer washer and two O-rings in right side housing.

See note above.

5046

Install the left side housing on the stand. Use work stand 2520 and fixture 5046.

#### Install inner tube and spacer washer.

Lubricate the end of the inner tube so that it enters easily and install with spacer washer.



#### Install outer tube.

#### J12

J11

Make sure the tube and the holes have well rounded edges so they do not damage the O-ring.

Align the tube so that the screw holes correspond.



Check the position of the outer tube. Check the alignment of the lock screw holes.

# TO TO BOOR

126 957

126 955

Condition: Tube hole too far in.

Difference permitted:  $0-0.5 \text{ mm} = 0-0.02^{\circ}$ .

Remove the tube and add spacer washers, see step J16.

#### Condition: Tube hole too far out.

Difference permitted: 0-0.5 mm = 0-0.02''. Bemove the tube and try thing

Remove the tube and try thinner spacer washers, see step J16.

# P/N Thickness 1206978 1.5 mm = 0.06" 84218 0.35 mm = 0.014" 84219 0.10 mm = 0.004"

#### Spacer washers available.

#### Note:

These spacer washers must be installed between the snap ring and the existing spacer washer.

J17

After corrections; remove the outer tube.

52 Group 64 Steering J15

J13

J14





54 Group 64 Steering

J27





Insert right side housing, with connecting pipe and rubber seal. Align hole in housing to correspond with hole for lock bolt.

Make sure edges of tube and stop screw hole are chamfered. Lubricate the end of the tube.

J28

Use an aluminum washer. Torque:  $19\pm 2$  Nm =  $14\pm 1.5$  ft.lb.

Install the lock bolt.

Caution: do not overtighten as this will cause the rack to bind.

J29 Install outer race for pinion lower bearing. Only if the bearing is replaced.

Lubricate pinion and rack. Use grease 1161001-1.



#### Install the pinion.

The rack should protrude 48 mm = 1.89" with the pinion in place. The pinion flat side should be toward the rack end.

Be careful when installing the pinion, not to damage the valve.

The flat portion for the lock bolt should be in one of the three positions shown.

Make sure rack and pinion engage properly,

J30



125.01



| For fee   | ler gauge<br>inch | Qty | Gasket<br>P/N |
|-----------|-------------------|-----|---------------|
| 0.20-0.25 | 0.008-0.010       | 1   | 1206931       |
| 0.25-0.35 | 0.010-0.014       | 1   | 1206934       |
| 0.35-0.45 | 0.014-0.018       | 2   | 1206931       |
| 0.45-0.60 | 0.018-0.024       | 1   | 1206931       |
|           |                   | 1   | 1206934       |
| 0.50-0.70 | 0.020-0.028       | 2   | 1206934       |

5054

J35 Use chart to determine gasket of correct thickness.

#### Install gasket.

Then install tool 5054.

This tool will then remain in place until adjusting balance procedures are finalized (at op. K28).

Install the O-ring.

J37

J38

J36



Install the valve housing. Be careful, not to damage house or valve.



Make sure the coil spring does not become squeezed under the cover.

Torque:  $19 \pm 2$  Nm =  $14 \pm 1.5$  ft.lb.

Note: Late production steering gears are equipped with a dust shield.



114 502

#### Adjust pinion shaft position.

Input shaft shoulder should be 1.5 mm = 0.06" above the cover face.

To adjust the position, turn the lower bearing with tool 5049.



#### Install shaft nut.

Position the lock plate and the nut. Use tool 5033 to hold when tightening the nut.

Do not lock the lock plate.

J39

J40



#### J43



#### Measure clearance.

Place the pre-tensioning piston, without O-ring, in the housing. Measure clearance between piston and housing.

Use ruler and feeler gauge. Press the piston against the rack. Push the rack in and out to determine maximum clearance.

#### Measure shims.

to obtain a correct play.

J44



The shims chosen should equal the clearance measured plus 0.05-0.15 mm = 0.002''-0.006''



Install spring and O-ring.

J45

Install shims and cover. Torque:  $19\pm 2$  Nm =  $14\pm 1.5$  ft.lb.

125 605





#### Check pinion torque.

Use torque gauge 9177 and adapter 5053 to crank the rack in and out between end positions.

Correct torque: 0.9-1.7 Nm = 8-15 in.lbs.

If torque in any place is excessive, stop rack in that position and readjust pretension. If the rack jams with pre-tensioning piston removed, rack is warped and should be replaced.

Note: use socket 5179 for late production steering gears.

#### Attach the oil pipes.

Early production 3/16" pipes, late production 1/4" pipes.

#### Install the tie rods.

Left and right side tie rods can be swapped to obtain unused lock portion

Do not use a tie rod with broken lock.

Use a 30 mm = 1-3/16" wrench to turn. Use a 7/8" wrench to hold on the outermost tooth.

#### Lock the tie rods.

Use a narrow punch to lock the ball joints in the rack recesses.









Power steering gear, Cam Gear Installation

J51



Install the rubber bellows and tighten the clamps.

#### J52

Adjusting valve and filling oil and "fluid grease" is made after the steering gear is installed.

Also see operation K31.

## Installing power steering gear type Cam Gear

Including adjusting balance

#### Special tools

5175, 5176 Nipples 5049 Sleeve 5055 Oil pressure gauge

#### Lubricants:

"Lubricant for steering gear" Volvo P/N 1161001-1 Automatic Transmission fluid (ATF)

K1



Position the steering gear while attaching the pinion shaft to the steering shaft. Make sure the pinion shaft recess becomes correctly aligned for the lock bolt.

Note: the dowel pins must be removed if a new steering gear is installed in an older vehicle without dowel pin holes.

To adjust steering shaft, see operations A25-A34.

#### K2

#### Install right side U-bolt and spacer.

Do not tighten the nuts fully.

Note: spacer block, spacers and U-bolt must be used for late production installations.



Power steering gear, Cam Gear Installation



Install left side retaining screws.

Use washers and spacers. Tighten all screws and U-bolts.

K3

K4

K5

Torque:  $20\pm5$  Nm =  $14\pm4$  ft.lbs.

Attach the tie rods to the steering arms. Torque:  $60\pm10$  Nm =  $44\pm7$  ft.lbs.



Connect the steering shaft.

Install the lock bolt. Check that no tension remains in the steering shaft joints. Tighten the nut. Torque:  $25\pm5$  Nm =  $18\pm4$  ft.lbs.

K6 Connect the oil return line to the steering gear.

K7

#### Connect test instrument.

Use nipples 5175 and 5176 to connect test instrument 5055.

The hose from the instrument valve should be connected to the steering gear.

Nipples 5175 and 5176 are used instead of previous nipples 2865 and 2990.

#### 6-cyl. Models:

126 989

178 695

5175

Connect test instrument 5055 between the power pump and the oil pressure hose.

#### K8 Position the pressure gauge in front of the windshield.

Turn the dial so that it can be easily read from the driver's seat.

#### K9

K10

#### Fill oil in power steering oil container.

Fill ATF oil, start engine and idle. Fill until level has stabilized at correct level.

# Train the second second

5055

5176

5055

5176 -

5175

#### Turn steering wheel slowly to right side and left side end positions.

Turn several times with slow motion to let the pump work with low pressure. Fill oil as necessary. Stop turning wheel when oil in container is almost free from bubbles.

Install the container cover.



#### Remove steering wheel padding.

Insert a screwdriver between the padding and a spoke. Pry up.

Late production units: pry loose the center cover.

#### K12

K11



Turn the steering wheel to almost right end position. Connect a torque gauge to the steering wheel center nut. Use the torque gauge to turn slowly to the right. Read the torque when the pressure gauge reading reaches 1.2 MPa = 170 psi.

It is very important that the torque reading is noted exactly when the pressure is reached. The pressure will remain if the torque is lowered in this position.

#### K13

## Check balance when turning the steering wheel to the left.

Turn the steering wheel to the left. Read the torque the same way as for right side.

K14

#### Torque reading.

Correct reading: 3.5–5.0 Nm = 30–40 in.lbs. Incorrect reading may indicate incorrect pump pressure.

#### K15

#### Torque difference between sides.

Difference between sides must not exceed 1.0 Nm = 0.73 ft.lb. = 8.8 in.lb.

If difference is excessive, balance must be adjusted.

K16

#### Adjusting balance.

Stop the engine. Remove nut and lock washer from pinion lower bearing.





#### K17

K18

#### Adjusting balance.

Turn the lower pinion bearing race.

Lock washer in original position provides 9 full adjustment steps, each giving a pressure difference of 1 Nm = 8.8 in.lbs.

Lock washer in reversed position gives 9 additional intermediate steps. The first one giving a pressure difference of 0.5 Nm = 4.4 in.lbs.

# Lower pressure reading when turning right.

Example: pressure difference is 1 Nm.

Unfold the lock washer tab. Bend in the next tab, to the left of the unfolded tab.

#### Turn the bearing race to the left.

Use tool 5049. Turn until the race recess fits the lock tab.

#### K19

# Lower pressure reading when turning left.

Example: pressure difference is 1 Nm.

Unfold the lock washer tab. Bend in the next tab, to the right of the unfolded tab.











66 Group 6 Steering





68 Group 64 Steering





Late prod. 6-cyl. Models: Attach the clamp on the front axle member.

#### Final check.

Start the engine. Turn the steering wheel from stop to stop, with a slow and even movement. Check fluid level, refill as necessary. (ATF).

# abc abc

#### Install wheels.

Use the markings to avoid rebalancing. Torque:  $120\pm 20$  Nm =  $90\pm 15$  ft.lbs.

#### Check/adjust toe-in.

Use rust protective oil to seal the tie rod threads. Lock nut torque:  $70\pm10$  Nm =  $50\pm7$  ft.lbs.

|                   | angle 2 a | A-a                       | B-b                     | C-c                     |
|-------------------|-----------|---------------------------|-------------------------|-------------------------|
| Manual steering   | 24'±8'    | 4.5±1.5 mm<br>3/16"±1/16" | 3.5±1 mm<br>9/64"±1/32" | 2.5±1 mm<br>3/32"±1/32  |
| Power<br>steering | 16'+8'    | 3.0±1.5 mm<br>1/8"±1/16"  | 2.0±1 mm<br>5/64"±1/32" | 1.5±1 mm<br>1/16"±1/32" |



K39

K36

K37
### Power steering gear type ZF

Checking balance

#### Special tools:

5055 Oil pressure gauge 5175, 5176 Nipples



71 Steering

Power steering gear, ZF Checking balance





## Check balance when turning the steering wheel to the right.

#### Start the engine.

Turn steering wheel to almost right end position. connect a torque gauge to the steering wheel center nut. Use the torque gauge to turn slowly to the right. Read the torque when the pressure gauge reading reaches 2.0 MPa = psi.

It is very important that the torque reading is noted exactly when the pressure is reached. The pressure will remain if the torque is lowered in this position.

## Check balance when turning the steering wheel to the left.

Turn the steering wheel to the left. Read the torque the same way as for right side.

### Torque reading.

Correct reading: 4–4.5 Nm = 35–40 in.lbs. Incorrect reading may indicate incorrect pump pressure.

Difference between sides must not exceed 0.5 Nm = 4.4 in.lbs.

If difference is excessive, the steering gear should be replaced.



L5

## Power steering pump Saginaw

Disassembly

#### Special tools:

2863 Drift 5047 Puller 5051 Puller



Power steering pump, Saginaw Disassembly



74 Group 64 Steering

Power steering pump, Saginaw Disassembly





Power steering pump, Saginaw



N2

N3

N4

N1

Power steering pump, Saginaw Assembly



Power steering pump, Saginaw Assembly





T)

Install flow control valve and spring.

Check end play.

Use dial gauge. Correct end play: 0.05-0.10 mm = 0.002-0.004''.

N11

N12

N10

### Install O-rings and magnet.

The magnet will collect ferric particles which may be suspended in the oil.

### Install the oil reservoir.

128.618

Oil the O-rings (ATF). Install the oil reservoir, with a new O-ring.

N9

Power steering pump, ZF Disassembly

# Power steering pump ZF

Disassembly



80 Group 64 Steering

Power steering pump, ZF Disassembly

04



### Remove rotor and cam ring.

Turn pump over, tap lightly on end until parts fall free.

If the cam ring does not come loose, let it remain until later on.

Remove ball bearing retaining ring.

Press out the shaft.

115 523

06

07

05



0

Push out thrust ring. Also push out cam ring, if remaining.

Power steering pump, ZF Disassembly





#### Remove O-rings.

Check all parts for wear and scratches. Replace worn or damaged parts. Replace all O-rings.

09

If the pump housing bushing is defective, replace housing assembly. Rotor, vanes and cam ring are also replaced as an assembly.





Power steering pump, ZF Assembly



84 Group 64 Steering

Power steering pump, ZF Assembly

P5

P6



Install the cam ring. Install on dowel, arrow UP.

115 634



1

Install inner O-ring. One of the O-rings is smaller.

Install rotor assembly.

P7

Install with recessed round shaft hole DOWN, toward drive side.

Vanes with rounded ends toward cam ring.



P8 Install pressure plate. The dowel pin should align in one of the outer holes.

Power steering pump, ZF Assembly



Power steering pump, ZF Assembly



Install the plug Use a new copper seal. Hex 27 mm.

P14

P13



Install the shaft seal Tap lightly until the seal is properly seated.





VOLVO SUPPORTS VOLUNTARY MECHANIC CERTIFICATION BY THE N.I.A.S.E.

(U.S.A. only)

| Service literature                     |
|--|
| Your<br>most important<br>special tool |



TP 30001/3 4500.8.84 Printed in U.S.A.