

Service Manual

• Repairs and maintenance

Section 3 (34)

Ignition systems

240, 260
1975–

VOLVO

Volvos are sold in versions adapted for different markets.
These adaptations depend on many factors including legal, taxation and market requirements.

This manual may therefore show illustrations and text which do not apply to cars in your country.

Group 34 Ignition system

Contents

	Page
Special tools	2
General instructions	3
Specifications: Ignition system with contact breaker	5
Breakerless ignition system	10
Computerized ignition system	21
Inspection of Ignition system with contact breakers B 20 A, B 17-B 23 A	24
Breakerless ignition system B 20 F, B 19 E, ET, B 21 E, ET, F FT, B 23 E, B 27/28 A, E and F	37
Computerized ignition system B 21 F-MPG (1981), B 21 F-CI (1982), B 21 F-LH (1982), B 23 F-LH (1983-1984), B 230 F-LH (1985-)	57

Index page 79


Indicates revised information:

Order number: TP 30432/2


We reserve the right to make alterations
without prior notification.

Special tools

999	Description—Use
9724	Ohm-Diode Tester
9921	Monotester – Dwell angle, ignition setting
9940	Stroboscope – Ignition setting
5275	Flywheel Adapter – Ignition setting MY 1984–




132/935



137/188




Ignition system – general instructions



Measuring resistance

Before measuring the resistance of a component make sure that all leads have been disconnected from it.

Resistance values specified in this manual apply at 20°C (68°F).



Electronic ignition systems

Electronic ignition systems operate at very high voltages – often in excess of 30 000 V. Such high voltages are a danger to life and special precautions must be taken when working on vehicles so fitted.

The symbol used throughout this manual indicates terminals where dangerous high voltages can be expected.



USA/Canada


-1980: VC 244 45 L 1000000
1981-: YV1 AX 45 4X B 1000000

Other markets

-1980: 245 45 L 1000000
1981-: YV1 244 46 1B 1000000

Engine type and model year designation

11 = B 317 (B 20 1975–76)	6 = B 27 (1975–79)
2 = B 19	61 = A
21 = A	64 = E (–1980)
24 = E	65 = F
26 = E-Turbo	6 = B 28 (1980–)
4 = B 21	62 = A
41 = A	68 = E (1981–)
44 = E	69 = F
45 = F (5)	8 = B23/B230
46 = E-Turbo	81 = A
47 = F-Turbo	84 = E
48 = F (8)	88 = F
49 = F (9)	




Bosch part numbers

Stamped in side of distributor body.

Specifications

Ignition system with contact breaker

B 20 A, B 17-B 23 A

Ignition coil

131 763

A-engines - 1978 A-engines 1979-

Resistance of primary coil (across terminals 1(-) and 15(+))	$2.85 \pm 0.15 \Omega$	$1.9 \pm 0.1 \Omega$
Resistance of secondary coil (across terminals 1(-) and HT terminal)	$9.5 \pm 2.5 \text{ k}\Omega$	$9.5 \pm 1.5 \text{ k}\Omega$
Ballast resistor	-	$1.3 \pm 0.1 \Omega$ ($0.9 \pm 0.1 \Omega$ early 79)

Spark plugs

137 530

B 20	Bosch W 7 B
B 17-B 23	Bosch W 7 DC
Electrode gap	0.7-0.8 mm
Tightening torque (un{oiled} plug)	$25 \pm 5 \text{ Nm}$ ($18 \pm 3.5 \text{ ft.lbs}$)

High tension leads*

	240	240	
1975			
	1kΩ	0Ω/m	1kΩ
1976-80			
	0Ω	5.6 kΩ/m	1.4 kΩ
1981-			
	0Ω	5.6 kΩ/m	1kΩ
		0Ω	
		136 523	
			136 524

*Note: Resistance values are given in $\text{k}\Omega$ -per-meter of length. (Measure lead in order to compute correct value.) All values have a permissible tolerance of $\pm 20\%$.

Specifications

Ignition system with contact breaker

Rotor


Resistance $5 \pm 1 \text{ k}\Omega$



Firing order


B 20

1-3-4-2



B 17-B 23

1-3-4-2



134 578

Ignition setting

With effect from 1976, vehicles for Sweden, Australia, USA and Canada (also Switzerland 1983-models) have details of ignition setting stamped on a plate to left of engine compartment.

Ignition setting (before T.D.C., vacuum control unit disconnected)			
Engine type	Model year/Market	11.7–13.3 r/s 700–800 r/min	41.7 r/s 2500 r/min
B 17 A	1979–84	12°	28–32°
B 19 A	1977 ¹⁾ 1978 Italy 1978–80 Other markets 1981–84	15° 15° 12° 10°	32–36° 32–36° 28–32° 26–30°
B 19 K		7°	17–23°
B 20 A	1975–76	10°	23–27°
B 21 A	1975 1976–77 ¹⁾ 1978 Sweden ³⁾ Other markets 1979–80 ²⁾ 1981 Scandinavia, Australia Other markets 1982–83 Scandinavia, Australia Canada Other markets 1984 Scandinavia, Switzerland Australia Europe Canada	12° 15° 12° 15° 12° 10° 12° 10° 7° 12° 10° 10° 7° 12° 10° 10° 7° 7°	24–28° 32–36° 28–32° 32–36° 28–32° 26–32° 28–32° 26–32° 24–30° 28–32° 20–26° 26–32° 17–23° 24–30°
B 23 A	1981–82 Scandinavia ⁴⁾ 1982 Other markets 1983–84 Europe Overseas	7° 5° 7° 5°	21–26° 19–24° 17–22° 19–24°

Special vehicles

¹⁾ Sweden: 245 with BW 35, BW 55, M 46 and special vehicles 10°

²⁾ 1979–80: Sweden, Overseas with engine types 498 755 and 498 811 and special vehicles with manual gearbox 10°

Special vehicles with automatic gearbox 8°


³⁾ 240 with engine type 498 528 15° and 32–36°

⁴⁾ Ignition setting can be retarded to 5° if, despite using 98 octane fuel, engine is prone to pre-ignition (knocking).


Special vehicle refers to heavy vehicle types such as 245 GL with automatic transmission.

Distributor

Engine type	Model year	Market (Applies to all markets unless otherwise stated)	Bosch No.	Volvo No.
B 17 A	1979–80 1981–84		0 231 176 103 0 185	1 266 478 1 219 661
B 19 A	1977 1978 1979 1980 1981–84	Italy Other markets Thailand, Malaysia, Indonesia Other markets	0 185 0 185 6 103 6 103 0 185 6 103 0 185	1 219 661 1 219 661 1 266 478 1 266 478 1 219 661 1 266 478 1 219 661
B 19 K	1984		0 302	1 332 410
B 20 A	1975–76		0 085	462 657
B 21 A	1975 1976–77 1978 1979 1980 1981–83 1984	Sweden, Canada Other markets Sweden, Australia, Canada, Overseas Other markets (incl. Thailand, Indonesia) Sweden, Australia, Canada, Overseas Other markets (incl. Malaysia, Thailand, Indonesia) Canada Sweden, Australia (1982 – also Switzerland, Canada) Other markets Europe Australia, Canada	0 134 0 173 0 185 6 103 0 185 6 103 0 185 6 103 0 284 0 185 0 302 0 284	463 692 1 219 625 1 219 661 1 266 478 1 219 661 1 266 478 1 219 661 1 266 478 1 306 792 1 219 661 1 332 410 1 306 792
B 23 A	1981–82 1983–84	Europe Other markets	0 287 0 302 0 287	1 306 872 1 332 410 1 306 872

Ignition setting


Bosch number at bottom left of diagrams is stamped in distributor body.

**Diagram key:**

Variation of ignition setting with vacuum









Variation of ignition setting with engine rpm



Specifications

Ignition system with contact breaker

Ignition setting graphs



Bosch no.	0231 170 085	0231 170 134	0231 170 173	0231 170 185	0231 176 103	0231 170 284	0231 170 287	0231 170 302
Volvo no.	462 657	463 692	1219 625	1219 661	1 266 478	1 306 792	1 306 872	1 332 410
Direction of rotation	Anti-clockwise	Clockwise	Clockwise	Clockwise	Clockwise	Clockwise	Clockwise	Clockwise
Contact breaker gap, mm	min. 0.35	min. 0.40	min. 0.40	min. 0.40				
Dwell angle at 8.3 r/s (500 r/min)	62±3°	62±3°	62±3°	62±3°	62±3°	62±3°	62±3°	62±3°
Contact pressure, N (kp)	*6.5–8 (0.65–0.80)	*6.5–8 (0.65–0.80)	*6.5–8 (0.65–0.80)	*6.5–8 (0.65–0.80)	*6.5–8 (0.65–0.80)	6.5–8.0 (0.65–0.80)	6.5–8.0 (0.65–0.80)	6.5–8.0 (0.65–0.80)

*1978: B 19 A Italy, B 21 A excluding Sweden.

Centrifugal governor

Total advance, distrib. degrees	13±1	15±1	13±1	12.5±1	15±1	12.5±1	12.5±1	12.5±1
Advance begins at distrib. r/s (distrib. r/min)	9.2–10.8 (550–650)	7.1–9.6 (425–575)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	6.7–10 (400–600)	7.5–9.2 (450–550)	7.7–9.6 (460–575)	6.7–10 (400–600)

DATA

5° at distrib. r/s (distrib. r/min)	15.8–19 (950–1 140)	13.8–16.7 (830–1 000)	14.2–17.5 (850–1 050)	13.3–16.3 (800–975)	13–14.3 (780–860)	13.0–16.5 (780–990)	13.8–17.3 (825–1 040)	15.8–20.8 (950–1 250)
10° at distrib. r/s (distrib. r/min)	23.2–26.3 (1 390–1 580)	20.8–28.0 (1 250–1 680)	20.8–26.7 (1 250–1 600)	20–22.9 (1 200–1 375)	20.8–25.2 (1 250–1 510)	19.3–22.8 (1 160–1 370)	24.0–35.5 (1 440–2 130)	25.8–30.8 (1 550–1 850)
Max. advance at distrib. r/s (distrib. r/min)	29.2 (1 750)	37.5 (2 250)	31.7 (1 900)	25.8 (1 550)	33.3 (2 000)	25 (1 500)	41.6 (2 500)	33.3 (2 000)

Vacuum control

Direction of control	Positive							
Total control, distrib. degrees	6.5±1	7±1	7±1	5±1	7.5±1	7.5±1	7.5±1	7.5±1
Control begins at mm Hg	60–100	230–300	235–290	135–180	110–145	110–150	110–145	110–150
Data:								
2° at mm Hg	85–130	—	275–320	175–215	130–170	130–170	135–170	135–170
5° at mm Hg	130–180	320–400	335–390	—	165–210	165–210	165–215	170–210
Max. control at mm Hg	175–185	400	400–410	255–265	220	220–230	230–240	220–240

Direction of control	—	—	—	—	Negative	—	—	—
Total control, distrib. degrees	—	—	—	—	2.5±0.5	—	—	—
Control starts at mm Hg	—	—	—	—	80–160	—	—	—
Data:								
1° at mm Hg	—	—	—	—	95–180	—	—	—
Max. control at mm Hg	—	—	—	—	200	—	—	—


Specifications

Breakerless ignition system

Specifications Breakerless ignition system

B 20 F, B 19 E, ET, B 21 E, ET, F, FT, B 23 E, B 27 A, E, F, B 28 A, E, F

Ignition coil



131 753

B 20, B 19-B 23 B 27/B 28

Resistance of primary coil across terminals 1(–) and 15(+) ...	1.9±0.1 Ω	0.5±0.1 Ω
Resistance of secondary coil terminal (across terminals 1(–) and HT) ...	9.5±1.5 kΩ	9.5±1.5 kΩ
Ballast resistor	0.9±0.1 Ω	1±0.1 Ω

Spark plugs

4-cyl engines

B 20 F	–1976	Bosch W 6 B
B 19 E, B 21 E	1975–84	Bosch W 6 DC
B 19 ET, B 21 ET		Bosch W 6 DC
B 21 F	1976–79	Bosch W 7 DC
	1980–82 USA	Bosch WR 7 DS
	1980–84 Others	Bosch W 7 DC
B 21 FT	1981–85	Bosch WR 7 DS
B 23 E	1979–80	Bosch W 5 DC
	1981–84	Bosch W 6 DC



131 930

Electrode gap ... 0.7–0.8 mm

Tightening torque (unoiled plug) ... 25±5 Nm (18±3.5 ft.lbs)

6-cyl engines

B 27 A	1975–79	Bosch H 6 D
B 27 E	1975–78	Bosch H 6 D
	1979–80	Bosch H 5 D
B 27 F	1976–79	Bosch H 6 D
B 28 A and E	1980–84	Bosch H 6 D
B 28 F	1980–84 USA	Bosch HR 6 DS
	1980–84 Others	Bosch H 6 D



131 529

Electrode gap ... 0.6–0.7 mm




Tightening torque (unoiled plug) ... 12±2 Nm (8.7±1.5 ft.lbs)

Rotor

Resistance

 $5 \pm 1 \text{ k}\Omega$ **High tension leads***

134 578



*Note: Resistance values are given in K Ω -per-meter of length. (Measure lead in order to compute correct value.) All values have a permissible tolerance of $\pm 20\%$.

Firing order**B 20**


1-3-4-2

**B 19-B 23**

1-3-4-2

**B 27, B 28**

1-6-3-5-2-4



Specifications

Breakerless ignition system

Ignition setting (before T.D.C. with vacuum control unit disconnected)

With effect from 1976, vehicles for Sweden, Australia, USA and Canada (also Switzerland 1983-models) have details of ignition setting stamped on a plate to left of engine compartment.

4-cyl E-engines

Engine type	Model year/market	Notes	11.7–13.3 r/s 700–800 r/min	41.7 r/s 2500 r/min
B 19 E	1977–83 1984		8° 10°	28–33° 24–28°
B 19 ET	1982–84		15°	21–26°
B 21 E	1975–82 ¹⁾		8°	28–33°
B 21 ET	1981–84		15°	21–26°
B 23 E	1979–82 1983 Canada 1984 Other markets		5° 10° 5° 10°	25–30° 25–29° 25–30° 25–29°

¹⁾ 1976–80: Australia, Sweden Special vehicles

5

4-cyl F-engines

B 20 F	1975		5°	20–25°
B 21 F	1976 1977 USA Other markets 1978 1979 California, Japan Other markets 1980 Canada Other markets 1981–84 Japan 1981 USA		15° 12° 15° 12° 8° 10° 10° 8° 8°	25–30° 28–32° 25–30° 28–32° 22–26° 26–30° 24–28° 22–26° 22–26°
B 21 FT	1981–85	Adjust at 15 r/s (900 r/min)	8°	26–30°
B 21 FT	1981–85	Adjust at 15 r/s (900 r/min)	12°	26–30°

6-cyl A and E-engines

B 27 A	1975–79		10°	22–25°
B 28 A	1980–84		10°	22–25°
B 27 E	1975 1976 Sweden, Australia Other markets 1977–78 1979–80		10° 10° 10° 10° 10°	30–34° 22–26° 30–34° 30–34° 25–29°
B 28 E	1981–82 1983–84		10° 12°	25–29° 27–31°

¹⁾ 1978: Sweden, Australia, Special vehicles

8

6-cyl F-engines

B 27 F	–1976 1977 California Other markets 1979		10° 7° 10° 10°	27–32° 20–24° 27–32° 20–24°
B 28 F	1980–82	Adjust at 15 r/s (900 r/min) Applies to: 1981: California, Japan 1982: All	10°	20–24°

Distributor

4-cyl E-engines

Engine type	Model year	Description	Bosch P/N D 237 00. . .	Volvo P/N
B 19 E	1977–83 1984		2 017 2 039	1 219 957 1 276 403
B 19 ET	1982–84		3 027	1 276 701
B 21 E	1975 1976 1977–80 1981–82	Sweden, Australia Other markets Sweden, Australia (Overseas 1979–) Other markets (incl. Thailand 1979–)	2 001 2 010 2 001 2 010 2 017 2 017	463 832 1 219 662 463 832 1 219 662 1 219 957 1 219 957
B 21 ET	1981–84		3 027	1 276 701
B 23 E	1979–82 1983 1984	Canada Other markets	2 017 2 039 2 017 2 039	1 219 957 1 276 403 1 219 957 1 276 403

4-cyl F-engines

B 20 F	1975	BW 35 (California: to engine no. 500) M 40/M 41 (California: to engine no. 500) California BW 35 (engine no. 501–) California M 40/M 41 (engine no. 501–)	2 003 2 002 2 009 2 008	462 762 462 896 1 218 672 1 218 671
B 21 F	1976	USA	2 007	463 694
	1977	Canada, Japan	3 003	1 219 848
	1978	California, Canada, Japan	2 007	463 694
	1979	Other markets	3 009	1 266 466
	1980–81	California, Japan (Canada –1980)	3 003	1 219 848
	1980–84	Other markets	2 039	1 276 403
	1981–82	USA (Canada 1981–82)	2 038	1 266 904
	1980–84	Japan	2 039	1 276 403
B 21 FT	1981–84		2 039	1 276 403
			3 024	1 276 703

6-cyl A and E-engines

Engine type	Model year	Description	Bosch P/N D 237 40. . .	Volvo P/N
B 27 A	1975–79		2 006	269 995
B 27 E	1975 1976 1977–78 1979–80	Sweden, Australia Other markets Sweden, Australia Other markets	2 001 2 005 2 001 2 005 2 007 2 013	269 323 269 565 269 323 269 565 269 733 1 269 191
B 28 A	1980–84		2 006	269 995
B 28 E	1981–84		2 013	1 269 191

6-cyl F-engines


B 27 F	–1976 1977–78 1979	Japan, Canada USA	2 004 2 004 6 001 6 004	269 134 269 134 269 739 1 269 291
B 28 F	1980–84		2 017	1 269 380

Specifications

Breakerless ignition system

Ignition setting graphs

Bosch number at bottom left of diagrams is stamped in distributor body.








Legend









Variation of ignition setting with vacuum









Variation of ignition setting with engine rpm











Specifications

Breakerless ignition system



Specifications

Breakerless ignition system



4-cyl

Bosch no.	0237 002 001	0237 002 002	0237 002 003	0237 002 007	0237 002 008	0237 002 009	0237 002 010	0237 002 017
Volvo	463 832	462 896	462 762	463 694	1 218 671	1 218 672	1 219 662	1 219 957
Direction of rotation	Clockwise	Anti-clockwise	Anti-clockwise	Anti-clockwise	Anti-clockwise	Anti-clockwise	Clockwise	Clockwise
Resistance of impulse sender pole kΩ	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25

Centrifugal governor

Total advance, distrib. degrees	15±1	14.5±1	14.5±1	11±1	11±1	11±1	15±1	15±1
Advance begins at distrib. r/s (distrib. r/min)	7.7–9.2 (460–550)	7.5–9.2 (450–550)	7.2–9.2 (430–550)	7.8–9.5 (470–570)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	7.7–9.2 (460–550)	7.7–9.2 (460–550)

DATA

5° at distrib. r/s (distrib. r/min)	13.2–15.7 (790–940)	13.8–16.8 (830–1 010)	13.8–16.8 (830–1 010)	15–18.3 (900–1 100)	13.3–16.2 (800–970)	12.5–15.3 (750–920)	13.2–15.7 (790–940)	13.2–15.7 (790–940)
10° at distrib. r/s (distrib. r/min)	19–20.8 (1 140–1 250)	20.5–23.3 (1 230–1 400)	20–23.3 (1 200–1 400)	29.2–40 (1 750–2 400)	19.7–22.5 (1 180–1 350)	25–32.5 (1 500–1 950)	20.8–25.8 (1 250–1 550)	18.2–20.7 (1 090–1 240)
Max. advance at distrib. r/s (distrib. r/min)	33.3 (2 000)	26.7 (1 600)	36.7 (2 200)	40 (2 400)	22.5 (1 350)	32.5 (1 950)	33.3 (2 000)	33.3 (2 000)

Vacuum control

Direction of control	Positive	—	—	—	—	—	Positive	Positive
Total control, distrib. degrees	4±1	—	—	—	—	—	4±1	8±1
Control begins at mm Hg	140–200	—	—	—	—	—	140–200	140–190
Data:								
2° at mm Hg	170–230	—	—	—	—	—	170–230	165–220
5° at mm Hg	—	—	—	—	—	—	—	205–270
Max. control at mm Hg	210–240	—	—	—	—	—	210–240	270–300

Direction of control	—	Negative	Negative	Negative	Negative	Negative	—	—
Total control, distrib. degrees	—	2.5±1	2.5±1	5±1	2.5±1	2.5±1	—	—
Control begins at mm Hg	—	30–110	30–110	60–110	30–110	30–110	—	—
Data:								
1° at mm Hg	—	45–115	45–115	65–120	45–115	45–115	—	—
Max. control at mm Hg	—	90–120	90–120	120–150	90–120	90–120	—	—

Breakerless ignition system

Specifications

4-cyl

Bosch no.	0237 002 038	0237 002 039	0237 003 003	0237 003 009	0237 003 024	0237 003 027
Volvo	1 266 904	1 276 403	1 219 848	1 266 466	1 276 703	1 276 701
Direction of rotation	Clockwise	Clockwise	Clockwise	Clockwise	Clockwise	Clockwise
Resistance of impulse sender pole kΩ	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25	0.95–1.25

Centrifugal governor

Total advance, distrib. degrees	14±1	12.5±1	14.5±1	14.5±1	12.5±1	11.5±1
Advance begins at distrib. r/s (distrib. r/min)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	7.5–9.2 (450–550)	6.7–10.0 (400–600)

DATA

5° at distrib. r/s (distrib. r/min)	15–19.2 (900–1 150)	13.7–17.5 (820–1 050)	14.2–17.5 (850–1 050)	14.2–17.5 (850–1 050)	14.2–17.5 (850–1 050)	20.5–26.3 (1 250–1 575)
10° at distrib. r/s (distrib. r/min)	24.2–28.3 (1 450–1 700)	25–35.8 (1 500–2 150)	20.8–29.2 (1 250–1 750)	20.8–30.3 (1 250–1 820)	25–35.8 (1 500–2 150)	32.5–38.3 (1 950–2 300)
Max. advance at distrib. r/s (distrib. r/min)	33.3 (2 000)	41.7 (2 500)	42.5 (2 550)	41.7 (2 500)	41.7 (2 500)	40 (2 400)

Vacuum control

Direction of control	Positive	Positive	Positive	Positive	Positive	Positive
Total control, distrib. degrees	7.5±1	7.5±1	4±1	7.5±1	7.5±1	7.5±1
Control begins at mm Hg	120–145	110–140	145–200	105–155	95–140	110–140
Data:						
2° at mm Hg	130–170	130–170	165–225	125–175	120–170	135–170
5° at mm Hg	170–210	170–210	—	165–220	155–215	170–220
Max. control at mm Hg	220–230	220–230	215–245	215–245	225–245	230–245

Direction of control			Negative	Negative	—	—
Total control, distrib. degrees			3.5±1	3.5±1	—	—
Control begins at mm Hg			105–160	95–160	—	—
Data:						
2° at mm Hg			125–190	125–190	—	—
Max. control at mm Hg			170–200	170–215	—	—

Pressure control

Direction of control	—	—	—	—	Negative	Negative
Total control, distr. degrees	—	—	—	—	5±1	2.5±1
Control begins at mm Hg	—	—	—	—	95–170	110–180
Data:						
1° at mm Hg	—	—	—	—	110–210	125–210
Max. control at mm Hg	—	—	—	—	225–275	185–230

6-cyl

Bosch no.	0237 402 001	0237 402 004	0237 402 005	0237 402 006	0237 402 007	0237 402 013	0237 402 017	0237 406 001	0237 406 004
Volvo	269 323	269 134	269 565	269 995	269 733	1 269 191	1 269 380	269 739	1 269 291
Direction of rotation	Clockwise								
Resistance of impulse sender pole									
kΩ	540–660	540–660	540–660	540–660	540–660	540–660	540–660	540–660	540–660

Centrifugal governor

Total advance, distrib. degrees	14±1	14±1	14±1	14±1	14±1	13±1	11±1	14±1	11±1
Advance begins at distrib. r/s (distrib. r/min)	7.9–9.6 (475–575)	7.9–9.6 (475–575)	7.9–9.6 (475–575)	7.9–9.6 (475–575)	7.9–9.6 (475–575)	7.5–9.2 (450–550)	8.3–9.6 (500–575)	8.3–10.0 (500–600)	8.3–10.0 (500–600)

DATA

5° at distrib. r/s (distrib. r/min)	13.3–15.8 (800–950)	12.9–15.4 (775–925)	15.8–19.2 (950–1 150)	15.8–18.8 (950–1 125)	12.9–15.4 (775–925)	12.5–15.4 (750–925)	12.5–15 (750–900)	12.5–15 (750–900)	12.5–15 (750–900)
10° at distrib. r/s (distrib. r/min)	19–20.8 (1 140–1 250)	18.3–25.8 (1 100–1 550)	24.2–27.5 (1 450–1 650)	24.2–27.5 (1 450–1 650)	18.3–20.8 (1 100–1 250)	23.3–31.7 (1 400–1 900)	30–35.8 (1 800–2 150)	23.3–28.3 (1 400–1 700)	31.3–34.6 (1 875–2 075)
Max. advance at distrib. r/s (distrib. r/min)	33.3 (2 000)	36.7 (2 200)	33.3 (2 000)	33.3 (2 000)	40 (2 000)	35.8 (2 400)	34.2 (2 150)	35 (2 050)	35 (2 100)

Vacuum control

Direction of control	Positive	—	Positive						
Total control, distrib. degrees	4±1	—	4±1	6±1	7.5±1	7.5±1	10±1	7.5±1	7.5±1
Control begins at mm Hg	140–200	—	140–200	150–190	140–200	170–210	105–140	125–170	120–140
Data:									
2° at mm Hg	170–230	—	170–230	180–215	200–260	200–240	120–145	140–195	150–190
5° at mm Hg	—	—	—	220–250	290–350	240–275	140–165	180–235	190–230
Max. control at mm Hg	210–240	—	210–240	245–255	400	290–310	200–210	230–260	230–250
Direction of control	Negative	—	—	—	—	—	Negative	Negative	Negative
Total control, distrib. degrees	5±1	—	—	—	—	—	5±1	5±1	5±1
Control begins at mm Hg	50–100	—	—	—	—	—	50–115	50–90	50–90
Data:									
2° at mm Hg	75–125	—	—	—	—	—	85–145	90–130	90–130
Max. control at mm Hg	130–155	—	—	—	—	—	145–180	160–170	160–170

Breakerless ignition system
Specifications


Specifications

Computerized ignition systems

B 21 F-MPG 1981, B 21 F-Cl 1982, B 21 F-LH 1982, B 23 F 1983-1984

B 230 F 1985-

Ignition coil



131 753

Resistance of primary coil (across terminals 1(-) and 15(+))
Resistance of secondary coil (across terminals 1(-) and HT terminal
Capacitor, terminal 1(-)

Essex
 $1.2 \pm 0.1 \Omega$

Bosch
 $1.2 \pm 0.1 \Omega$

$10.6 \pm 1.0 \text{ k}\Omega$
 $50-250 \text{ nF}$

$8.5 \pm 0.8 \text{ k}\Omega$

Spark plugs



137 530

B 21 F, B 23 F
B 230 F
Electrode gap
Tightening torque (unoiled plug)

Bosch WR 7 DS

Bosch WR 7 DC

$0.7-0.8 \text{ mm}$

$25 \pm 5 \text{ Nm} (18 \pm 3.5 \text{ ft.lbs})$

High tension leads

Resistance of lead between ignition coil and distributor
Resistance of spark plug suppressor
Resistance of distributor suppressor

$5.6 \text{ k}\Omega/\text{m}$

$5 \text{ k}\Omega$

$1 \text{ k}\Omega$

Firing order

1-3-4-2



136 451

Ignition setting (vacuum governor on control unit disconnected); see instructions on page 65.

Engine type	Model year		11.7-13.3 r/s 700-800 r/min	41.7 r/s 2 500 r/min
B 21 F	1981-82		12°	22-30°
B 23 F, B 230 F	1983-		12°	16-24°

Specifications

Computerized ignition systems

Distributor

Engine type	Model year	Remarks	Volvo P/N
B 21 F	1981-82		1 306 059
B 23 F	1983 1984		1 332 684 1 336 737
B 230 F	1985-		1 332 587

Ignition advance graphs, control unit

Legend:



Variation of ignition setting with vacuum





Max vacuum advance in relation to engine rpm.





Variation of ignition setting with engine rpm

Example control unit P/N 1306057: at 30 r/s (1 800 r/min) vacuum advance cannot be more than 90° regardless of extent of depression.



B 21 F-MPG 1981



B 21 F-CI 1982





B21F-LH 1982





B23F-LH Auto transmission 1983-84 Manual gearbox 1983 engine P/N 499802

(Changed engine version 1983)





B23F-LH Manual gearbox 1983 engine P/N 499890 Manual gearbox 1984



Contents

Computerized ignition systems, Ignition system with contact breaker assembly

B 230 F-LH 1985-



Ignition system with contact breaker assembly

Contents

Ignition coil and HT leads

Operation

Page

A1-A4

26

Distributor cap and rotor arm

B1-B2

27

Replacing contact breaker points

B3-B15

28

Checking ignition setting

B6

29

Checking centrifugal advance

B7

29

Checking vacuum advance

B8-B14

30

Reconditioning distributor

C1-C6

32

Replacing vacuum control unit

C1-C2

32

Replacing distributor

C3-C4

32

Checking side play

C5

33

Lubrication



C6

33

Distributor test bench

D1-D4

34



137-520

A. Ignition coil and HT leads



136 464


A1

Testing ignition coil, ballast resistor and HT leads

Test-conditions:

Components should be at a temperature of about 20°C (68°F).

All leads must be disconnected from the components when taking measurements.



137 631

A2

Measuring resistance of ballast resistor

Ballast resistor fitted to 1979 models onwards:

Resistance: 0.9Ω (early 79)

1.3Ω (others)



137 524

A3

Checking ignition coil:

- check outer casing of ignition coil for cracks etc.
- measure resistance across terminals 1(–) and 15 (+).

Resistance: $2.7-3.0 \Omega$ – 1978

$1.8-2.0 \Omega$ 1979-84



137 525

- measure resistance across terminal 1(–) and high tension terminal.


Resistance: $7.0-12.0 \Omega$ – 1978

$8.0-11.0 \Omega$ 1979-84

Checking resistance* of HT leads

	240		240	
1975		1 kΩ		0 Ω/m
				1 kΩ
1976-80		0 Ω		5,6 kΩ/m
				0 Ω
1981-		0 Ω		5,6 kΩ/m
				0 Ω
				136 523
				1975
				1975-76
				1976-
				136 524

*Note: Resistance values are given in $k\Omega$ -per-metre of length. (Measure lead in order to compute correct value.) All values have a permissible tolerance of $\pm 20\%$.

B. Distributor

134 577

B1

Distributor cap

Check for:

- dirt
- cracks
- burnt terminals, tracking
- worn rotor.




134 578

B2

Checking rotor

Replace rotor if cracked or excessively burnt.

Resistance = $5 \pm 1 k\Omega$.



136 469


Replacing contact breaker points

Grease cams after installing new points.

Turn crankshaft until fibre heel on contact breaker is on top of cam.

Adjust gap to 0.40 mm on B 17–B 23.
0.35 mm on B 20

Apply 1–2 drops of engine oil to spindle wick.




136 466

Adjust dwell to 59–65°

Volvo Monotester or dwell meter.

Reduce points gap to decrease dwell angle and increase gap to increase angle.

Refit rotor and distributor cap.

**Check dwell angle at 42 r/s (2500 r/min)**

If dwell angle differs by more than 2° from reading at idle, check distributor for wear.

**Adjust ignition setting at 11.7–13.3 r/s
(700–800 r/min)**

Disconnect hose from vacuum unit on distributor.
Adjust ignition timing to value indicated in table below.



Check centrifugal advance at 42 r/s (2500 r/min)

Check that ignition advance is according to specification, see table below. If advance is not according to specification, check advance weight assembly.

Ignition setting

With effect from 1976, vehicles for Sweden, Australia, USA and Canada (also Switzerland 1983-models) have details of ignition setting stamped on a plate to left of engine compartment.

Ignition setting (before T.D.C., vacuum control unit disconnected)			
Engine type	Model year/Market	11.7–13.3 r/s (700–800 r/min)	41.7 r/s (2500 r/min)
B 17 A	1979–84	12°	28–32°
B 19 A	1977 ¹⁾	15°	32–36°
	1978 Italy	15°	32–36°
	1978–80 Other markets	12°	28–32°
	1981–84	10°	26–32°
B 19 K	1984	7°	17–22°
B 20 A	1975–76	10°	23–27°
B 21 A	1975	12°	24–28°
	1976–77 ¹⁾	15°	32–36°
	1978 Sweden ³⁾	12°	28–32°
	Other markets	15°	32–36°
	1979–80 ²⁾	12°	28–32°
	1981 Scandinavia, Australia	10°	26–32°
	Other markets	12°	28–32°
	1982–83 Scandinavia, Australia	10°	26–32°
	Canada	7°	24–30°
	Other markets	12°	28–32°
	1984 Scandinavia, Switzerland	10°	20–26°
	Australia	10°	27–33°
	Europe	7°	17–23°
	Canada	7°	24–30°
B 23 A	1981–82 Scandinavia ⁴⁾	7°	21–26°
	1982 Other markets	5°	19–24°
	1983–84 Europe	7°	17–22°
	Overseas	5°	19–24°

Special vehicles

¹⁾ Sweden: 245 with BW 35, BW 55, M 46 and special vehicles

10°

²⁾ 1979–80: Sweden, Overseas with engine type 498 755 and 498 811 and special vehicles with manual gearbox

10°


³⁾ 240 with engine type 498 528

15° and 32–36°

⁴⁾ Ignition setting can be retarded of 5° if, despite using 98 octane fuel, engine is prone to pre-ignition (knocking).

Special vehicle refers to heavy vehicle types such as 245 GLE with automatic transmission.

B8

**Vacuum advance/retard**

Some distributors are equipped with a vacuum control unit with two vacuum hoses. In such cases the control unit regulates both vacuum advance and retard.



136 468

B9

Delay valve

Because of exhaust emission laws some vehicles are equipped with a delay valve connected between the inlet manifold and vacuum control unit.

Several different types of valves are in use. On all types "DIST" must face distributor.

Check that it is possible to suck air through "DIST" side of valve and that it is very difficult to blow air through same side.




B10

Checking vacuum advance

Connect a vacuum pump to vacuum control unit. Run engine at idle speed and record ignition advance. Increase vacuum and check that ignition advance increases.

If ignition advance does not increase check vacuum control unit.



136 469


B11

Checking vacuum retard

Run engine at idle speed.

Check that ignition is retarded when vacuum hose is connected.

If not, check condition of hose. If hose is in good condition check vacuum control unit.



134 582



Check vacuum advance with a vacuum pump

Check distributor number and find correct ignition advance graph on pages 7 and 8.

Select a pressure from graph and pump up vacuum pump to this value.

Record ignition advance.

Subtract basic ignition setting from recorded ignition advance and check that value conforms to graph.



136 878



135 321

Example: Bosch number 0 231 170 287 on B 23A 1981-82 Sweden

You decide to check vacuum advance at 200 mm Hg.

Recorded advance at this pressure is found to be 16-21°.

Basic ignition setting = 7°.

Difference = 9 - 14° which is as specified.

Check vacuum unit for leakage

Connect a vacuum pump. Increase vacuum to 500 mm Hg (67 kPa).


Record pressure for 1 minute. Pressure must not drop by more than 100 mm Hg (13.5 kPa).

Pre-ignition – B 23A Sweden 1981-82

If, despite use of 98 octane fuel, engine is prone to pre-ignition (knocking), ignition can be retarded to 5°.

Ignition setting can also be retarded to 2° before T.D.C. if vehicle is required for towing purposes. Note that fuel consumption will increase and that ignition should be reset to specification during normal usage.

C. Reconditioning distributor




C1

Replacing vacuum control unit

(B 20: distributor must be removed from engine before vacuum unit can be replaced. See operation C3.)

Remove:

- distributor cap
- rotor
- condensation trap
- vacuum hose.



C2

Mark position of distributor

Turn distributor to obtain access to vacuum unit retaining screws.

Replace vacuum unit.

Turn distributor back to mark.

Fit:

- condensation trap
- rotor
- distributor cap
- vacuum hose.

Check/adjust ignition setting.



C3

Replacing distributor

Remove:


- distributor cap
- condensation trap.

Disconnect:

- wire
- vacuum hose.

Turn crankshaft until rotor points towards scribed line in distributor body.

Remove retaining screw and lift away distributor.




C4

To install:

- turn rotor approx. 60° clockwise away from line in distributor body. (Does not apply to B 20)
- fit distributor
- rotor should now point towards line. Reconnect vacuum hose and wire. Fit condensation trap and reclamp distributor cap.

Check/adjust ignition timing.




136 679

Checking side play of distributor shaft


Max side play = 0.2 mm (0.079 in). Fit a new distributor if side play is greater than 0.2 mm.

Lubrication



A = distributor grease P/N 116 1136-7 or Bosch Ft1v4
B = distributor grease P/N 116 1136-7 or Bosch Ft1v26

D. Testing distributor on a test bench



Refer to the manufacturer's instructions at all times when testing distributors on a test bench.

The number on the side of the distributor is the Bosch part number.

D1

Checking dwell angle

Condition: New contact breaker points.

Run distributor at 3.5–4.2 revs/sec (200–250 r/min).


Adjust dwell angle to 59–65°. (It is advisable to set dwell angle to 59° as angle increases as cam wears.)

Increase speed to 25 r/s (1500 r/min).

Read off dwell angle.

Dwell angle must not vary by more than 2° from previous setting.

Check distributor for wear, damage etc if deviation is too great.



D2

Checking firing

Run distributor at 3–5 revs/sec (200–300 r/min) on test bench.

Set distributor "0" to position which corresponds to firing of cylinder 1.

Firing should be 0–90–180–270°.

Increase speed.

Check shape of arrows (or equivalent symbol depending on test unit).

If deviation is more than 2° this indicates that side play is too large or cam is worn.



D3

Checking mechanical advance

Run distributor at 3.5 r/s (200 r/min). Calibrate meter. Increase speed and check that mechanical advance conforms to specification.

If not, check that balance weights are lubricated and do not bind.

Also check springs.





137 192

Checking vacuum advance

Run distributor at 10 r/s (600 r/min).




Calibrate meter.

Increase vacuum and compare value to specification.


Breakerless ignition system

Contents

	Operation	Page
Ignition coil and HT leads	E1–E4	38
Checking distributor cap and rotor	F1–F2	39
Checking impulse sender and air gap	F3–F4	40
Checking ignition advance	F5–F11	40
Basic-setting	F5	40
Mechanical advance	F6	40
Vacuum advance	F7–F10	42
Retard	F11	43
Reconditioning distributor	G1–G28	43
Replacing vacuum control unit	G1–G2	43
Replacing distributor B 19–B 23	G3–G4	44
Replacing impulse sender B 19–B 23	G5–G11	44
Replacing distributor B 27/B 28	G12–G21	47
Replacing impulse sender B 27/B 28	G22–G27	49
Checking side play	G28	51
Lubrication	G29	52
Replacing control unit	G30	52
Testing distributor on test bench	G31–G34	53
Wiring diagram		55
Fault tracing		56



137 526



137 527

E. Ignition coil and HT leads

E1



Testing ignition coil, ballast resistor and HT leads


Test conditions:

- Ignition coil and ballast resistor at approximately 20°C (68°F)
- All leads disconnected from components under test.

E2

Measuring resistance of ballast resistor

B 20, B 19–B 23	$0.9 \pm 0.1 \Omega$
B 27, B 28	$1.0 \pm 0.1 \Omega$
(Both resistors are connected in series)	



E3

Checking ignition coil

- check outer casing for cracks
- measure resistance across terminals 1(–) and 15(+).

B 20, B 19–B 23	$1.9 \pm 0.1 \Omega$
B 27, B 28	$0.5 \pm 0.1 \Omega$



- measure resistance across terminal 1(–) and HT terminal.

All models: $9.5 \pm 1.5 \text{ k}\Omega$.




Checking HT leads*

	260	240	
1975	0 Ω 1.4 kΩ/m 0 Ω	1975	1 kΩ 0 Ω/m 1 kΩ
1976	1 kΩ 0 Ω/m 1 kΩ	1976-80	0 Ω 5.6 kΩ/m 0 Ω
1977	0 Ω 5.6 kΩ/m 0 Ω 136 521	1981+	0 Ω 5.6 kΩ/m 0 Ω 136 523
	260	240	
1975	0 Ω 1.4 Ω/m 0 Ω	1975	0 Ω 0 Ω/m 1.4 kΩ
1976	1 kΩ 0 Ω/m 10 kΩ	1975-76	1 kΩ 0 Ω/m 1 kΩ
1977-78	0 Ω 5.6 kΩ/m 0 Ω	1976+	1 kΩ 0 Ω/m 5 kΩ
1979	0 Ω 5.6 kΩ/m 0 Ω 136 522		136 524

*Note: Resistance values are given in K Ω -per-meter of length. (Measure lead in order to compute correct value.) All values have a permissible tolerance of $\pm 20\%$.

F. Distributor

F1



Checking distributor cap

Check for:

- cracks
- burnt electrodes, tracking
- carbon brush for wear or damage

Important! To prevent retaining springs from damaging rotor do not crank engine when distributor cap is off.



Checking rotor

Rotor should be free from cracks and electrode should not be burnt.

Measure resistance. Resistance = 5 ± 1 kΩ.

F2

F3


**Checking impulse sender**

Measure resistance of sender.

B 20, B 19–B 23	0.95–1.25 kΩ
B 27, B 28	0.54–0.66 kΩ

Check that no arcing to earth occurs.

If meter pointer swings to far right (i.e. open circuit) remove impulse sender and check if sender or lead is defective.



F4

Checking air gap

Set rotor and stator tips opposite each other and measure air gap with feeler gauge.

6 cyl engines: min 0.3 mm (0.012 in)

4 cyl engines: min 0.25 mm (0.010 in).

Adjust if necessary.



F5

Checking/adjusting basic setting at 11.7–13.3 r/s (700–800 r/min)

Disconnect hose from vacuum control unit.

Adjust ignition setting to specification. See next page.



F6

Checking centrifugal advance at 42 r/s (2500 r/min)

Check that ignition advance is according to specification. See next page.

If not, examine centrifugal advance mechanism.

Ignition setting (before T.D.C., disconnected vacuum control unit)

With effect from 1976, vehicles for Sweden, Australia, USA and Canada (also Switzerland 1983-models) have details of ignition setting stamped on a plate to left of engine compartment.

4-cyl E-engines

Engine type	Model year/Market	Description	11.7–13.3 r/s (700–800 r/min)	41.7 r/s (2500 r/min)
B 19 E	1977–83 1984		8° 10°	28–33° 24–28°
B 19 ET	1982–84		15°	21–26°
B 21 E	1975–82 ¹⁾		8°	28–33°
B 21 ET	1981–84		15°	21–26°
B 23 E	1979–82 1983 1984	Canada Other markets	5° 10° 5° 10°	25–30° 25–29° 25–30° 25–30°

¹⁾ 1976–80: Australia, Sweden Special vehicles

5

4-cyl F-engines

B 20 F	1975		5°	20–25°
B 21 F	1976	USA, California Other markets	15°	25–30°
	1977		12°	28–32°
	1978		15°	25–30°
	1979	California, Japan Other markets	12°	28–32°
	1980	Canada Other markets	8° 10°	22–26° 26–30°
	1981–84		10° 8° 8°	24–28° 22–26° 22–26°
B 21 FT	1981–85	Adjust at 15 r/s (900 r/min)	12°	26–30°

6-cyl A and E-engines

B 27 A	1977–79		10°	22–25°
B 28 A	1980–84		10°	22–25°
B 27 E	1975	Sweden, Australia Other markets	10°	30–34°
	1976		10°	22–26°
	1977–78 ¹⁾		10°	30–34°
	1979–80		10°	30–34°
	1980–82		10°	25–29°
B 28 E	1983–84		12°	27–31°

¹⁾ 1978: Sweden, Australia Special vehicles

8

6-cyl F-engines

B 27 F	–1976 1977 1979	California Other markets	10° 7° 10° 10°	27–32° 20–24° 27–32° 20–24°
B 28 F	1980–82	Adjust at 15 r/s (900 r/min) for 1981 – California	10°	20–24°




F7

Checking vacuum advance

Connect a vacuum pump to vacuum unit.

Run engine at idle speed and record ignition advance. Pump vacuum pump and check that ignition setting advances.


If ignition setting does not advance check vacuum control unit.



F8

Check Bosch number on distributor and turn to appropriate graph on pages 16–20


Select pressure from graph and pump up vacuum pump to this value. Record ignition setting. Subtract basic ignition setting and check that value conforms to graph.



F9

Example: Bosch number 0 237 002 038**B21 F 1979 – (Excl. California and Japan)**

You select a pressure of 200 mm Hg. Crankshaft degrees at this pressure = $9-14^\circ$. Basic ignition setting is 10° which means that $19-24^\circ$ should be recorded at timing test.



F10

Check vacuum control unit for leakage

Connect a vacuum pump and increase vacuum to 67 kPa (500 mm Hg).

Pressure should not drop by more than 13.5 kPa (100 mm Hg) during one minute.

**Checking ignition retard**

Applies to B19/21E and F-Turbo engines.

Connect pressure gauge 5230 and pump 5496 to vacuum control unit.

Start engine and run at idle.

Record ignition advance. Increase pressure to 30 kPa and read off ignition setting.

Ignition setting should drop 3–7°.

Disconnect pump and pressure gauge. Reconnect hose.

G. Distributor – reconditioning

G1

Replacing vacuum control unit

B20: Remove distributor from engine prior to removing vacuum unit.


Remove:

- distributor cap
- rotor
- dust cover
- vacuum hose.

Mark position of distributor.

Turn distributor to obtain access to vacuum unit retaining screws.

Remove vacuum unit.



136 471

G2

Hook on vacuum unit


Tighten screws.

Return distributor to original position.

Fit:

- vacuum hose
- dust cover
- rotor
- distributor cap.

Check ignition setting.



G3

Replacing distributor on B 19–B 23

Removing


Unclip distributor cap and remove dust cover.

Turn crankshaft until rotor points towards mark in distributor body, see fig.

Disconnect:

- wire
- vacuum hose.

Remove distributor retaining screw and lift away distributor.



G4

Installing

Turn rotor approx. 60° clockwise from mark in distributor body.

(Does not apply to B 20.)

Place distributor in position and fit screw loosely.

Check that rotor points towards mark.

Connect:

- wire
- vacuum hose.

Refit distributor cap.

Check/adjust basic ignition timing.



G5

Replacing impulse sender on B 19–B 23

Removing

Remove distributor as described in G3.

Remove/disconnect:

- retaining clips
- vacuum unit
- wire
- impulse sender screw.


G6

Unclip lock ring and remove shims as applicable


Remove rotor and lock pin

Use two screwdrivers to pry rotor off shaft.

Remove lock ring and lift out impulse sender.




136 476



109 178

G7

Fit new impulse sender




109 179

G8

Attach lock ring

G9



136 480


Fit rotor and lock pin

If lock pin has a groove turn it to face centre shaft.
Fit shims and lock ring.

G10

Fit/connect:

- impulse sender screw
- wire
- vacuum unit
- retaining clips.




136 475

G11


Turn shaft and check for grinding etc

Magnets will give slight resistance to turning action.
Refit distributor. See G14.
Check/adjust basic ignition setting.



109 252

Replacing distributor on B 27, B 28



G12


B 27 A, B 28 A start at operation G15

Other engine types:

Remove air filter.

B 27 E 1975–78


Proceed to G15.



G13

Remove front part of inlet manifold


Disconnect link rod from throttle pulley.



G14

Remove air-fuel control unit retaining screws

Lift unit up slightly.



G15

All B 27, B 28 models

Unclip distributor cap and lift out dust cover.


Turn crankshaft until rotor points towards mark in distributor body.

Remove/disconnect:

- vacuum hose
- wire
- screw.

Remove distributor.

G16




132 572

Installing distributor

Turn rotor to point towards clip.

Fit distributor.



134 584

G17

Check setting

Rotor should point towards mark in distributor body.

Fit retaining screw loosely.

Fit/connect:

- wire
- vacuum hose
- dust cover
- distributor cap.



137 194

G18


B27 A, B28 A proceed to G21

B27 E 1975–78 proceed to G20

Other B27 E models and B27 F, B28 E and B28 F

Install air-fuel control unit

Reconnect link rod to throttle pulley. Tighten air-fuel control unit screw.



114 244

G19

Refit inlet manifold

Tightening torque 10–15 Nm (7–11 ft.lbs.).

G20



Fit air filter

G21



All B 27, B 28

Check/adjust basic ignition setting.


G22


**Replacing impulse sender
on B 27/B 28**

Remove distributor according to G12–G15.

Remove:

- vacuum unit
- clips
- wire.





G23

Lift off rotor

Unclip lock ring and remove washer.

Lift off rotor. (Pry rotor off shaft with two screwdrivers if necessary.)

Take care not to drop lock pin into distributor.




G24

Remove impulse sender

Remove screws and lock ring.

Lift up sender.




Install new impulse sender

Remove screws from impulse sender.

Place base plate section on shaft.

Make sure that pins are opposite lug in distributor body.

Fit screws and lock ring.



G25

Refit rotor


If lock pin has a groove turn it to face centre shaft.

Fit shims and lock ring.

Refit:

- vacuum unit
- clips.

Reconnect wire.




136 477

G27

Turn shaft and check for grinding etc

Magnets will offer slight resistance to turning action.
Refit distributor. See G16–G21.




109 252

G28

Check distributor shaft side play


Max. side play = 0.2 mm (0.008 in).

If side play is greater than specified, replace distributor.



134 583

Lubrication



136 676


Replacing control unit

Make sure that rubber seal remains in bottom of connector when disconnecting control unit.




G30

Testing distributor on a test bench




Refer to the manufacturer's instruction at all times when testing distributors on a test bench.

The number on the side of the distributor is the Bosch part number.



134 586



- 1 Zero set at (360 r/min)
- 2 Electronic advance
- 3 and 4 Centrifugal advance begins
- 5 and 6 Centrifugal advance ends
- 7 Absolute limit of ignition advance

G31

Calibrate test bench

Set zero at distributor shaft speed corresponding to zero advance. See diagrams on pages 15–17. This compensates for the electronic advance from the impulse sender.

**Checking firing**

Set distributor "0" to position which corresponds to firing of cyl 1.

Firing should be:

4 cyl: 0–90–180–270

6-cyl: 0–75–120–195–240–315–360

Max. deviation = $\pm 1.5^\circ$.

Increase speed.

Check shape of arrows (or equivalent symbol depending on test unit).

If deviation is more than 2° this indicates that side play is too large.

Checking centrifugal advance

Run distributor at 3.5 r/s (200 r/min). Calibrate meter. Increase speed and check that centrifugal advance conforms to specification.

If not, check that balance weights are lubricated and do not bind.

Also check springs.

**Checking vacuum advance**

Run distributor at 10 r/s (600 r/min).


Calibrate meter.

Increase vacuum and compare value to specification.

Wiring diagram, breakerless ignition system

4 cyl

1975-1978




136 482

- | | |
|-----|------------------|
| A = | Control unit |
| B = | Ignition coil |
| C = | Ballast resistor |
| D = | Distributor |
| E = | Fuse box |
| F = | Starter motor |

6 cyl


1975-78



136 481

Colour code:


BL	= blue
GN	= green
BN	= brown
SB	= black
OR	= orange
R	= red
Y	= yellow
W	= white



Computerized ignition system

Contents	Operation	Page
General instructions	H1-H4	58
Connectors and earth points	J1-J4	59
Modifications to 1983 models	K1-K8	60
Ignition coil and HT leads	L1-L4	62
Checking distributor cap and rotor	M1-M3	63
Checking basic ignition setting	M4-M10	63
Checking/adjusting microswitch		
B 21 F-MPG 1981, B 21 F-CI 1982	M5-M6	64
B 21 F-LH 1982	M7	64
B 23 F-LH 1983-1984	M8-M9	65
B 230 F-LH 1985-		
Checking ignition advance	M11-M15	65
centrifugal advance	M11	65
vacuum advance	M12	66
dwell angle	M13	66
knock sensor	M14-M15	66
Reconditioning distributor (P/N 1306059)	N1-N4	67
replacing impulse sender	N1-N2	67
replacing distributor	N3-N4	67
Replacing distributor P/N 1332684, 1336737, 1332587	N5-N14	68
replacing impulse sender	N5-N8	68
replacing distributor	N9-N14	69
Replacing control unit	N15	70
Wiring diagram		71
Fault tracing		73

H. General instructions




H1

Always switch off the ignition when disconnecting/connecting ignition system terminals.



H2


Begin by checking all relevant terminals and connectors before carrying out extensive fault tracing procedures.



H3

Never let spark length exceed 5 mm when checking ignition system circuits or control unit may be damaged.


Consequently, connect spark plug to HT lead and earth plug via engine.



H4

CAUTION:

To avoid damaging the connector sleeves DO NOT DISCONNECT CONNECTOR from control unit when checking voltage. The volt-/ohm-meter should be connected directly to the wires.



J. Connectors and earth points




Control unit

J1




Distributor

J2



Bulkhead

J3



Control unit earth

J4

K. Modifications

Connecting guide sleeves




K1

With effect from 1983 models the distributor connector is equipped with guide sleeves. These sleeves can also be fitted to earlier models and to the control unit connector.

Guide sleeves P/N 1 324 909-9.

Note: From model-year 1984, the guide sleeves are installed in the control unit at the factory.



K2

Drift for connecting guide sleeves



P/N 999 5268-1.

To install guide sleeve, place sleeve in the drift and check that it protrudes 2 mm (0.08 in.).

If not, shorten tool to dimension shown adjacent.

Countersink tool.

Easier to insert guide sleeve if opening is countersunk.



K3

Carefully clean connector on distributor and control unit


Withdraw connector from distributor. Scrape off PVC and oxide deposits from all three pins.

Use tool 9549.

Apply grease to pin.

Clean female connector with a tapered file.

Withdraw connector from control unit. Scrape off oxide from around pins 3, 5 and 9.




K4

Place guide sleeve in tool 5268

Pack (A) with grease. Repeat for each sleeve.


Insert sleeve in tool.



K5

Install guide sleeves on connectors**Distributor:**


On all pins.



K6

Control unit

On pins 3, 5 and 9.



K7

Check

Press on guide sleeves so that at least 2 mm (0.08 in) of pin is visible above sleeves.

Reconnect terminals and check function.

Replacing sleeve insulators

K8

Withdraw connector

Detach rubber cover and remove insulator.

Fit new insulator P/N 949597-9.

Reconnect connector.

L. Ignition coil and HT leads




136 484

L1

Test conditions:

- Ignition coil and leads should be at a temperature of about 20°C (68°F).
- All leads must be disconnected from components when taking measurements.



137 524

L2

Checking ignition coil


- check outer casing for cracks etc
- measure resistance across terminals 1(−) and 15(+).
Resistance = 1.1–1.3 Ω.



137 525

L3

- measure resistance across terminal 1(−) and the high tension terminal.
Resistance = 9.6–11.6 kΩ.



L4


Checking HT leads

Resistance of HT lead between distributor and ignition coil should be 2–3.5 kohms which is equivalent to 5.6 kohms per metre.

Spark plug suppressor resistance = 5 kohms.

Resistance of cable connector on distributor cap = 1 kohm (each lead).

M. Distributor, general




M1

Checking distributor cap

Check for:

- dirt, cracks
- tracking, burnt terminals.


Note: Centre terminal is not spring loaded.



M2

Checking rotor


Two types of rotor are in use. Use only new type for replacement.



M3

Checking Hall pick-up wire

Make sure that the wires cannot be damaged by the rotor.



M4

Checking/adjusting basic ignition setting

Before checking ignition setting check function of microswitch.

Note: See page 65 for correct adjustment procedure.


M5

Checking microswitch on B21 F-MPG 1981 and B21 F-Cl 1982

Connect a test lamp between battery (+) and terminal 2 (yellow wire) on microswitch.

Lamp should be off when engine is idling. If lamp is on, adjust microswitch as described below.

Turn throttle pulley and check that lamp lights.



136 526


M6

Adjusting microswitch

Place a 0.4 mm feeler gauge between adjustment screw and lever.

Unscrew microswitch retaining screws and turn switch until lamp lights.

Retighten screws.




137 195

Checking

Place a 0.2 mm feeler gauge between adjustment screw and lever.

Lamp should light.

Remove feeler gauge and insert a 0.4 mm feeler gauge. Lamp should be off.



136 497

M7

Checking microswitch on B21 F-LH 1982

Disconnect connector from vacuum switch. Connect a test lamp between battery (+) and orange wire on switch.

Start engine.

Test lamp should light with engine idling.

Increase engine rpm and check that light goes out.

If not, check hose to vacuum switch. If intact, replace vacuum switch.


M8



**Checking microswitch on B 23F-LH 1983-1984;
B 230 F-LH 1985-**

With engine off, turn throttle pulley slowly and listen to microswitch. A click should be heard when throttle valve moves.

M9



Adjusting microswitch


Unscrew retaining screws.

Turn switch clockwise slightly. Then turn switch back until it contacts stop, but no further as throttle valve will start to open.

Tighten retaining screws.

Check function.

M10



Check that basic ignition setting is $12^\circ \pm 2^\circ$ at 12.5 r/s (750 r/min)

Warm engine.

Air conditioning disconnected as applicable.

Adjust ignition setting by turning distributor.

Increase engine speed to 2000 rpm for 5 seconds.

Let the engine idle and check idle quality.

Make sure the idle is stable and within specifications as variations could affect the timing.

M11

Check centrifugal advance

Disconnect vacuum hose from distributor.


Run engine at 42 r/s (2 500 r/min) and check that ignition advance is $16-24^\circ$ before T.D.C. for B 23 F, B 230 F and $22-30^\circ$ before T.D.C. for other models.

If incorrect, replace control unit.



136 472

M12



136 498


Check vacuum advance

Run engine at 25 r/s (1500 r/min).

Disconnect vacuum hose. Record ignition advance. Re-connect hose and check that advance alters.

If not, check for vacuum at control unit (check suction at hose).

If vacuum, but no advance, replace control unit.



M13

Check dwell angle

Read off dwell angle at idle.

Dwell angle = 36–38°.

Increase engine rpm and check that dwell angle increases. If no increase is recorded, replace control unit.




B 23 F

M14

Checking knock sensor

Connect a Volvo Monotester or equivalent test meter. Start engine (AC disconnected).

Increase engine speed and maintain at set level by e.g. placing screwdriver across throttle pulley.



136 527


M15

Tap plug on right side on cylinder block with a hammer. Ignition should retard by max 6° and return automatically to normal.


N. Distributor (Chrysler), reconditioning

Type 1 (P/N 1306059)

N1



T36 928



T36 499

Replacing Hall pick-up

Remove:

- distributor cap
- rotor arm/rotor
- springs retaining Hall pick-up
- disconnect connector
- remove Hall pick-up.

N2


Install:

- Hall pick-up
- springs
- rotor arm/rotor.

Check that wires cannot be damaged by rotor.

Refit distributor cap and reconnect connector.

See pages 60–61 for installing guide sleeves on connectors.



N3

Replacing distributor

Remove:

- HT leads from distributor cap
- distributor cap.

Turn crankshaft until rotor points towards rubber grommet.

Disconnect connector.

Remove distributor.

N4

Install distributor

Tubular pin protrudes more on one side than the other. Turn shaft until pin is opposite groove in distributor body.

Fit distributor.

Fit:

- rotor
- distributor cap and reconnect HT leads.

Reconnect connector.

Check/adjust basic ignition timing. See operation M4.

See pages 60–61 for installing guide sleeves on connectors.



Distributor (Bosch), reconditioning Type 2 (P/N 1332684, 1336737, 1332587)




N5

Replacing distributor

Remove/disconnect

- HT leads from cap
- distributor cap
- dust cover.

Refit rotor.




N6

Set cyl 1 to T.D.C.

Turn crankshaft until rotor points towards mark in distributor body.

Disconnect connector.

Remove distributor.



N7

Install distributor

Check that cyl 1 is at T.D.C.

Turn rotor approx. 60° clockwise from mark in distributor body.

Refit distributor.

Rotor should now point towards mark in distributor body.



N8

Fit/connect:

- dust cover
- rotor
- distributor cap
- HT leads.

Check/adjust basic ignition timing. See M4.

See pages 60–61 for installing guide sleeves on connectors.

Replacing Hall pick-up


N9

Note: The Hall Switch should not be replaced on distributors within the first year of warranty. The complete distributor must be replaced.

Remove distributor according to operations N5–N6.

Mount distributor in a vise (NOT SOFT VICE JAWS TO PREVENT DAMAGE).

Release circlip retaining trigger wheel.




N10

Pry off trigger wheel with two screwdrivers (use round-shaft screwdrivers, 5mm diameter).

Place tips of screwdrivers on steel hub, as shown.


Take care not to damage trigger wheel.



N11

Note: If trigger wheel is bent during removal, it must be replaced.



Take care not to lose lock pin.




N12

Remove

- circlip
- Hall pick-up retaining screws
- plastic pin (A) for connector




Remove Hall switch and connector.



N14

Install:


- New Hall switch and connector
- circlip
- retaining screws and plastic pin (1)



Install:

- trigger wheel (2)
- lockpin (3)
- circlip (4)
- condensation trap
- rotor arm

Install distributor according to operations N7–N8.




N15

Replacing control unit

Check centrifugal and vacuum advance according to operations M11–M13 after installing control unit.

See pages 60–61 for installing guide sleeves on connectors.

**Wiring diagram, computerized ignition systems
B 21 F-LH, B 23 F-LH**




136 512

Colour code

BL	= blue
GN	= green
BN	= brown
SB	= black
OR	= orange
R	= red
Y	= yellow
W	= white

Wiring diagram, computerized ignition system
B 230 F-LH, 1985-



- A Control unit
- B Ignition switch
- C Breaker unit
- D Fusebox
- E Knock sensor
- F Ignition coil
- G Distributor
- 214 Control Unit
LH Jetronic

Fuse No. 11

Heated rear window
Overdrive

Colour code


BL	= blue
GN	= green
BN	= brown
SB	= black
OR	= orange
R	= red
Y	= yellow
W	= white


NOTES

NOTES

← Replac

Fault tracing chart
B 21 F-MPG/LH B 23 F-LH









Repla

Fault tracing chart
B 230 F-LH


Engine starts and runs




OK



Yes




No



Yes

OK


Yes



Push test lamp probe through blue wire cover on control unit. Check for voltage.

(Voltage?)


Note: Do not disconnect connector from control unit.




Yes

No

Check control unit ground connection.



Check wires





Index

	Opera-	Page		
Dwell angle	tion			
Setting	B3-B4	28	Earth points	59
Checking, A engines (4 cyl)	B4-B5	28		
Checking B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	M13	66	Engine speed control	
			B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	M11
				65
Ballast resistor				
A-engines (4 cyl)	A2	26	Fault tracing	
E/F-engines, A-engines (6 cyl)	E2	38	E/F engines	56
			B 21 F-MPG/LH 23 F-LH	75
			B 230 F-LH	77
Centrifugal advance				
B 17A-B 23 A, B 19 K	B7	29	Firing order	11
B 19 E-B 23 E	F6	40		
B 27A-B 28 F	F6	40		
B 21-MPG-B 23 F-LH, B 230 F-LH	M8	65	Ground points	59
Connectors				
B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	J1-J3	59	Ignition coils	
			B 17 A-B 23 A	A1-A3
			B 19 E-B 23 E, B 27 A-B 28 F	E1-E4
			B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	L1-L4
Contact breaker				62
Replacement	B3	28	Ignition retard	
Checking dwell angle	B4	28	B 19/21 E and F-Turbo	F11
				43
Control unit				
B 19-B 23 E, B 27A-B 28 F	G30	52	Knock sensor	
B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	N16	70		
			Lubrication, distributor	
			B 17 A-B 23 A	C6
			B 19 E-B 23 E, B 27 A-B 27 F	G29
Delay valve	B9	30		
Distributor (B 17 A-B 23 A)			Microswitch	
Removing-installing	C3-C4	32	B 21 F-MPG, B 21 F-Cl 1982	M5-M6
Side play	C5	33	B 21 F-LH 1982	M7
Testing on test bench	D1-D4	34	B 23 F-LH 1983-1985, B 230F-LH	M8-M9
Lubrication	C6	33		
Distributor (B 19 E-B 23 E)			Sleeve insulators	
Removing-installing	G3-G4	44		
Replacement of impulse sender	G5-G11	44	Vacuum advance	
Side play	G28	51	B 17 A-B 23 A	B8-B14
Testing on test bench	G31-G34	53	B 19 E-B 23 E, B 27 A-B 28 F	F7-F10
			B 21 F-MPG, B 21 F-LH, B 23 F-LH, B 230 F-LH	M9
				65
Distributor (B 21 F-MPG-B 23 F-LH, B 230 F-LH)			Wiring diagram	
Removing-installing	N3-N4	67	B 21 F-MPG, B 21 F-LH, B 23 F-LH	
Replacement of Hall sender, type 1	N1-N2	67	B 230 F-LH	71
Replacement of Hall sender, type 2	N9-N14	69	B 230 F-LH	72
Distributor (B 27A-B 28 F)			Other E/F engines	55
Removing-installing	G12-G21	47		
Replacement of impulse sender	G22-G27	49		
Side play	G28	51		
Testing on test bench	G31-G34	53		

VOLVO

TP 30432/2

2000.10.85
Printed in U.S.A.