



MOUNTING INSTRUCTIONS
VOLVO - 279986 & 279987

Note: These Overrides are completely assembled and no additional hardware is required for mounting. DO NOT DISASSEMBLE.

1. Compare the contour of the cutout on the Overrides, to the contour of the Bumper, noting in particular that the Rubber Strip on the Bumper is wider on the Top than on the Bottom. Match this difference in thickness with the contour of the cutout to determine which end of the override to place upwards.
2. Next determine if it is a left or a right override. Note the stagger between the cutouts on each side of the override. The override is to be mounted with the narrow side facing the center of the vehicle. (see Note.)
3. The override is to be mounted directly in line with the bolts, holding the bumper to the inside legs of the Bumper Bracket.
4. Install vinyl strip provided along the entire edge of the cutout. Trim to proper length after installation.
5. Position Override, check to make certain that the angle on the ends of the strap matches the angle of the Bumper. Open straps slightly so as not to mar bumper when installing. Push into place until straps snap over edge of Bumper.
6. Secure by using a 3/16" "Hex Key" inserted thru hole in Bumper to tighten strap.
7. Seal Hole in Rubber by pushing into place one of the plugs provided.

Note: The rear overrides do not have a stagger in the cutout, therefore, step #2 can be omitted.