



MOUNTING INSTRUCTIONS  
VOLVO - 284012-2 & 284013-0

1. Remove Overrides from carton and look for the markings on the inside of the shell. You will find two shells marked front or two shells marked rear.
2. The shell is to be positioned over the approximately two inch wide portion of the rubber strip that is moulded thicker than the rest of the strip. To install the Overrides, hold only the shell against the bumper making certain that the Override will mount perpendicular to the vehicle. If the Override toes out, simply flip the shell over.
3. Slip one of the straps supplied over the bumper so that it straddles the bumper.
4. Install vinyl strip provided along the entire edge of the cutout. Trim to proper length after installation.
5. Insert 3/16" hex key into screw and engage screw thread into strap. Tighten securely.
6. Seal hole in rubber by pushing into place on the plugs provided.