

PRODUKT	AVD.	GRUPP	NR	DATUM
PRODUCT	SECTION	GROUP	NO.	DATE
ERZEUGNIS	ABT.	GRUPPE	NR.	DATUM
PRODUIT	SECTION	GROUPE	NO.	DATE

Monteringsanvisning

Einbauanleitung

Installation instructions

Notice de montage

## PAKKAUSOHJE AHTOILMANJÄÄHDYTIN B19 ET



## PACKING INSTRUCTIONS FOR B19 ET-IBS- INTERCOOLER BOOST SYSTEM

## FÖRPACKNINGSSANVISNING FÖR LADDLUFT- KYLARSATS FÖR B19 ET

# Issue 1

### SUOMI

Asennuksen helpottamiseksi kaikista osista on kuva tässä vihkosessa.

Pienet osat on pakattu muovipusseihin, joissa on sama numero kuin valokuvassa. Asennusohjeesta käy selville, missä kukin osa on.

Esimerkki: **On-off-venttiili [3]** = osasta on kuva valokuvassa 3 ja jos se on pienehkö osa, on se pakattu pussiin n:o 3.

### ENGLISH


To facilitate installation all parts are illustrated in this packing booklet. Smaller parts are packed in plastic bags which are numbered to correspond with the photographs. The text in the installation instructions indicates where each item can be found.

Example: **on-off valve [3]** = the item can be seen in photo 3, and if it is a small part, is packed in bag no 3.


### SVENSKA

För att underlätta monteringen finns alla detaljer avbildade i detta häfte. Mindre detaljer är packade i plastpåsar försedda med samma nummer som fotografiet. I texten i monteringsanvisningen lämnas uppgift om var varje detalj finns.


Exempel: **On-off ventil [3]** = detaljen finns avbildad på foto 3 och om det är en mindre detalj är den förpackad i påse nr 3.




1



2



3





10 10 10 10 10





10 10




4



5




6



# 7

**WARNING!  
ATTENTION!**

ROTERANDE FLÄKT OCH DRIVREMMAR  
ROTATING FAN AND DRIVE BELTS  
VENTILATEUR ET COURROIES  
EN MOUVEMENT **VOLVO** 1312187



## INTER-COOLER

PAKKA  
AHTOIL

PACKIN  
B19 ET

FÖRPA  
KYLARSATS FÖR B19 ET

ISSUE



*[Faint, illegible text in the left column, likely bleed-through from the reverse side of the page.]*

*[Faint, illegible text in the right column, likely bleed-through from the reverse side of the page.]*

*[Faint, illegible text in the left column, likely bleed-through from the reverse side of the page.]*

*[Faint, illegible text in the right column, likely bleed-through from the reverse side of the page.]*