

Reservdelar/Spare Parts

Datum/Date

Grupp/Group

Reg. nr/Reg. No.

810216

A 00

2 / 81

Utfärdare/Issuer

Godkänd av/Approved by

S Lundkvist

R Svensson

Ärende/Concerning

ÅRSMODELLER OCH CHASSINUMMER/
YEAR MODELS AND CHASSIS NUMBERS

Distribution

S No Da Fi Is Ö

Bifogade förteckningar upptar samtliga personvagnar, lastvagnar och bussar tillverkade fr o m 1961.

Observera att fordonen kan ha levererats senare. I förteckningen upptas sista planerade chassinummer för varje kalenderår för lastvagnar, bussar och äldre personvagnar.

Från 140-serien, 164 och senare personvagnar anges sista chassinummer per modellår. /

The attached lists specify all cars, trucks and buses produced in 1961 and later.

Please note that some vehicles are possibly delivered later than the production year. The years stated in the lists are calendar years for trucks, buses and older cars.

For the 140 Series and 164 as well as for later cars, the years mean model years. The chassis numbers mean the last vehicle produced during the calendar year or model year respectively.

Bilaga/
Appendix:

S No Da Fi Is Ö

PERSONVAGNAR/ CARS

SISTA CHASSINUMMER/ LAST CHASSIS NO - ÅR/ YEAR

A 00 2/81 Bilaga/Appendix
MODELLÅR/ YEAR OF MODEL

-1- (5)

	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980
PV 1100	345600	379035	405778	426546	440000															
PV 1200	96301	124544	150170	176552	206184	225049	234653													
PV 1300	1852	20615	57366	106768	172294	216949	279899	312499	339999	348474										
P 1800	2400	5999	9277	13650	18252	20999	25499	28299	30000	32799	32549									
P 182 (1800E)												39414								
P 183 (1800ES)												3069	8077							
P 2100	50089	57109	63904	71656	78981	83399	91099	95499	95546	97299										
P 2200		4039	11593	22209	35146	44599	61799	70299	73220											
P 142							1499	52899	112399	178960	249929	323399	393949	458306						
P 144							37099	89800	138699	194139	263069	340099	427999	519766						
P 145							9199	30899	61599	103379	153729	210049	268326							
P 164								12199	32399	52789	74449	102949	132566	153179						
242															53864	99679	122894	142124	165569	189179
244															82979	174909	274964	364649	482504	592109
245															54709	115349	163834	211324	264754	317940
262																2429	2569	4329	6449	8374
264															9674	34469	46514	62104	83054	107609
265																8114	10920	15734	21774	28319

		1975	1976	1977	1978	1979	1980	1981
Volvo 66	1)	A-53122	EC-101040	HC-118000	LC-144000	MC-163000	AC-179000	
	2)	A-92224	EC-117250	HC-142439	LC-161681	MC-177650	AC-193475	
	343 1)		EC-300093	HC-306000	LC-348000	MC-388000	AC-458000	BC-545500
	(340) 2)		EC-305381	HC-346559	LC-385807	MC-465078	AC-535996	

1) = Första chassinummer/First Chassis No.

2) = Sista chassinummer/Last Chassis No.

		1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976
DAF 22/23	1)	20000															
30-32	1)	31001	36000	56000	76000	106000	136000	168000									
33	1)							182200	190000	210000	231000	672000	753000	854000	944200		
	2)														952328		
	3)	14022	24121	17869	32536	29593	31413	18946	19113	20447	21277	19698	21088	19060	1831		
DAF 44	1)						500001		531000	576000	620000	672000	753000	840000	944200		
	2)																
	3)						2775	30731	16554	15325	17313	19794	22093	21507	21810		
DAF 46	1)														A-0001	A-20000	A-80000 600000
	2)																A-91093 603507
	3)														3353	22012	14600
DAF 55	1)							530000	531000	576000	620000	672000	753000				
	2)												821018				
	3)							1794	24335	28534	32167	43013	34387				
DAF 66	1)												812923	847500	944200	A-20000	
	2)															A-53121	
	3)												14197	58189	42983	39546	

- 1) = Första chassinummer/ First Chassis No.
 2) = Sista chassinummer/ Last Chassis No.
 3) = Producerat antal/ Number of cars produced

S No Da Fi Is Ö

LASTVAGNAR/ TRUCKS
SISTA CHASSINUMMER/ LAST CHASSIS NO - ÅR/YEAR

A 00 2/81 Bilaga/Appendix
MODELLÅR/ YEAR OF MODEL

-3-

	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978
LV 3700	4682	4874																
LV 3750	13336	13400																
LV 3851	306	370																
TL 3854	2149	2175																
L 4201 (F82B)	3506	4106	4591	4931	5206													
L 4251 (F82)				291	641	1241	1620	3122	3787	4377								
L 4301 (F83B)	4350	5171	5600	5960	6370													
L 4351 (F83)			723	1208	1652	2227	3166	4087	4932	5797								
L 4650	1175	3210	4550	6010	6995													
L 4750	645	1615	2105	2705	3002													
L 4751			1443	2533	3498													
L 4850	7894	11207	13802	16402	17962													
L 4851				576	1078													
L 4852	828	1103	1405	1605	1750													
L 4854				1377	2068													
L 4950	3251	4735	5919	7067	7612													
L 4951				484	953													
L 4952	1700	2335	3150	4010	4239													
L 4953		35	76	100														
L 4956				122	476													
F82, F82S						1241	1620	3122	3787	4377	4537	10226	10476	10786	10856			
F83, F83S						2227	3166	4087	4932	5797	6252	10389	10952	11422	11567			
N 84					519	2129	3734	4549	5719	6924	7479	7839						
F 85					514	2284	3554	5084	6819	8650	10545	12190	13765	15180	16240	17090	17672	17941

	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980
N86, N886					759	2884	3914	5465	7035	8693	10293	11593	12533							
F 86					302	1822	2952	4252	6057	8627	11458	15693	20338	24849	28449	31285	35265	38144 ²⁾		
FB 86							12	382	802	1417	1972									
N 88					468	1915	3024	4029	5738	7538	9153	23016	25216 ⁴⁾							
NB88					283	1253	1820	2570	3550	4730	5680									
NB88 6 x 4									20052 ³⁾	20271	20518									
F 88					328	1173	2138	3375	5043	6221	31662 ⁵⁾	34656								
FB 88					241	1231	2021	2681	3902	4597	31721 ⁵⁾		37891	41930	46790	50970	55661	58749 ⁶⁾		
FB 88 6 x 4										20158	20518									
									20034 ³⁾	31733 ⁵⁾										
F 89										103	1590	4570	7734	11558	15648	18538	20192	20719		
F 406-407															290	733	1045	2037	3271 ⁷⁾	
F 408															321	799	1325	2602	3790	4784
F 609-610															667	1844	2656	3421	4284	5296
F 611															300	1230	1874	2114	2555	3043
F 613															830	2050	3704	4924	7525	8863
F 614																		489	867	1196
F 615																		409	1192	1513 ⁷⁾
F 616																			132	1105
N 7													521	2335	4100	5503	7215	8898	9680	10337
N 10													959	4970	12264	19249	23538	27165	30574	34445
N 12													446	1143	2083	2719	3496	4342	5361	6813
F 7																		1914	8325	14078
F 10																115	2538	7812	12754	17467
F 12																118	1501	5095	9425	15390
C2 ¹⁾																	10370	11146	11877	12420 ⁷⁾
C3														386	2532	4777	6218	7298	8473	8564 ⁷⁾

- 1) = Första chassinummer/First Chassis No. 10001
2) = Antal byggda vagnar/Number of trucks produced 40116
3) = Första chassinummer/First Chassis No. 20000
4) = Antal byggda vagnar/Number of trucks produced 20049
5) = Första chassinummer/First Chassis No. 30000
6) = Antal byggda vagnar/Number of trucks produced 35567
7) = Sista chassinummer/Last Chassis Number

S No Da Fi Is Ö

BUSSAR/ BUSES

SISTA CHASSINUMMER/ LAST CHASSIS NO - ÅR/YEAR

A 00 2 /81 Bilaga/Appendix
MODELLÅR/ YEAR OF MODEL

-5-

	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980
B 6150, 6151 6159	5006	5489	5766	5950	6055															
B 6350	2536	2931	3241	3381	3575															
B 6550	1931	2296	2492	2589																
B 7050	468	538	606	650																
B 715		83	358	728	1078															
B 725	1059	1125																		
B 755			8	279	652															
B 54								5060	5195	5305										
B 57, BB 57						257	552	862	1192	1672	2264	2794	3514	4114	4805	5517	6200	6665	6765	7805
B 58						628	1163	1627	2206	2756	3583	4386	5376	6874	8784	10465	11924	13736	14153	16774 ²⁾
B 59											74	179	330	589	1251	1675	2081	2167 ²⁾	-	
B 6F (B 609)																105	235	370	450	501
B 10R ¹⁾																		3043	3249	3483
B 10M																				1738
B 6FA																				266

1) = Första chassinummer/First Chassis No. 3000

2) = Sista chassinummer